




OPERATORS MANUAL



NT30 DISC DRILL

AGCO-Amity JV LLC LIMITED WARRANTY TERMS AND CONDITIONS – UNITED STATES AND CANADA

EFFECTIVE FOR EQUIPMENT RETAILED AND DELIVERED AFTER JANUARY 1, 2020

WHAT IS WARRANTED AGCO Amity JV warrants its new equipment to be free of defects in material and workmanship at time of delivery to the first retail purchaser, renter, or lessee. These terms apply to all 10K, Amity, Concord, Wil-Rich and Wishek brands of new equipment originally marketed in the United States and Canada.

WARRANTY PERIOD

- 12 Months from the date of delivery to the first retail purchaser, renter or lessee.
- 483 Disk Chisel, Field Cultivator and Disk Cultivators: 3 years on main frames, wing frames, and shank assemblies
- Precision Shank Drill: 3 years on main frame, wing frame, and rockshafts.

EXCEPTIONS FROM THIS WARRANTY

- **Freight Charges** - This warranty does not cover freight charges.
- **Improvements, Changes, or Discontinuance** AGCO Amity JV reserves the right to make changes and improvements in design or changes in specifications at any time to any product without incurring any obligations to owners of products previously sold.
- **Repairs and Maintenance Not Covered Under Warranty** - This warranty does not cover conditions resulting from misuse, natural calamities, use of non-AGCO-Amity JV parts, negligence, alteration, accident, use of unapproved attachments, usage which is contrary to the intended purposes, or conditions caused by failure to perform required maintenance. Replacement of Wear or Maintenance items (unless defective) such as but not limited to, filters, hoses, belts, lubricants, light bulbs, wheel alignment, tightening of nuts, belts, bolts, and fittings, service tune-up, computer parameter adjustments and general adjustments which may from time to time be required are not covered.
- **Rubber Tire Warranty** - Rubber tires are warranted directly by the respective manufacturer only and not by AGCO Amity JV.
- **Satellite Outages** - Interruptions in satellite interfaces and satellite communications are outside the control of this product and are not covered by this warranty. The company is not responsible for issues or degradation of system performance resulting from such interruptions in satellite interfaces and satellite communications where the issues are not related to defects in this product.

OWNER'S OBLIGATION

It is the responsibility of the Owner to transport the equipment or parts to the service shop of an authorized AGCO Amity JV Dealer or alternatively to reimburse the Dealer for any travel or transportation expense involved in fulfilling this warranty. This Warranty does NOT cover rental of replacement equipment during the repair period, damage to products which have been declared a total loss and subsequently salvaged, overtime labor charges, freight charges for replacement parts, or special handling requirements (such as, but not limited to, the use of cranes).

EXCLUSIVE EFFECT OF WARRANTY AND LIMITATION OF LIABILITY

THIS WARRANTY IS IN LIEU OF ALL WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PURPOSE OR OTHER REPRESENTATIONS, WARRANTIES OR CONDITIONS, EXPRESSED OR IMPLIED. The remedies of the Owner set forth herein are exclusive. The Company neither assumes nor authorizes any person to assume for it any other obligation or liability in connection with the sale of covered machines. Correction of defects, in the manner and for applicable period of time provided above, shall constitute fulfillment of all responsibilities of AGCO Amity JV to the Owner, and AGCO Amity JV shall not be liable for negligence under contract or in any manner with respect to such machines. IN NO EVENT SHALL THE OWNER BE ENTITLED TO RECOVER FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES SUCH AS BUT NOT LIMITED TO, LOSS OF CROPS, LOSS OF PROFITS OR REVENUE, OTHER COMMERCIAL LOSSES, INCONVENIENCE OR COST OF RENTAL OR REPLACEMENT EQUIPMENT.

Some States or Provinces do not permit limitations or exclusions of implied warranties or incidental or consequential damages, so the limitations or exclusions in this warranty may not apply.

"AGCO Amity JV" AS REFERRED TO HEREIN WITH RESPECT TO SALES IN: UNITED STATES and CANADA: AGCO Amity JV LLC
PO Box 1030
Wahpeton, ND 58074

Additional Warranty Information

New Equipment Warranty - Equipment is eligible for warranty service only if it qualifies under the provisions of the New Equipment Warranty. The selling dealer will deliver this Warranty to the original retail purchaser at the time of sale, and the dealer will register the sale and Warranty with AGCO Amity JV LLC.

Subsequent Owners - This Warranty covers the first retail purchaser and all subsequent owners of the equipment during the specified warranty period. Should the AGCO Amity JV Dealer sell this equipment to a subsequent owner, the Dealer must deliver the warranty document to the subsequent owner so the subsequent owner can register ownership with AGCO Amity JV and obtain the remaining warranty benefits, if available, with no intermission in the Warranty Period. Subsequent Owner Procedure will apply. It is the responsibility of the subsequent owner to transport the equipment to the service shop of an authorized AGCO Amity JV Dealer or alternatively to reimburse the Dealer for any travel or transportation expense involved in fulfilling this warranty. This Warranty does NOT cover charges for rental or replacement equipment during the repair period, products which have been declared a total loss and subsequently salvaged, overtime labor charges, freight charges for replacement parts, or units sold at auction.

Warranty Service - To be covered by Warranty, service must be performed by an authorized AGCO Amity JV Dealer. It is recommended that you obtain warranty service from the Dealer who sold you the equipment because of that Dealer's continued interest in you as a valued customer. In the event this is not possible, warranty service may be performed by any other authorized AGCO Amity JV Dealers in the United States or Canada. It is the responsibility of the Owner to transport the equipment to the service shop of an authorized AGCO Amity JV Dealer or alternatively to reimburse the Dealer for any travel or transportation expense involved in fulfilling this warranty.

Maintenance Service - The Owner's Manual furnished to you with the equipment at the time of delivery contains important maintenance and service information. You must read the manual carefully and follow all the maintenance and service recommendations. Doing so will result in greater satisfaction with your equipment and help avoid service and warranty problems. Please remember that failures due to improper maintenance of your equipment are not covered by warranty.

Maintenance Inspections - To insure the continued best performance from your agricultural equipment, we recommend that you arrange to make your equipment available to your selling Dealer for a maintenance inspection 30 days prior to warranty expiration.

Narrow-Transport Grain Drill

1.Safety	9
1.1 Introduction	11
1.1.1 Safety alert symbol	11
1.1.2 Safety messages	11
1.1.3 Information messages.....	11
1.1.4 Safety signs	11
1.1.5 A word to the operator	12
1.1.6 This manual.....	13
1.2 Operation	14
1.2.1 Prepare for operation	14
1.2.2 General Information	14
1.2.3 Personal Protective Equipment.....	14
1.2.4 Seat Instructions	15
1.2.5 Shields and Guards	16
1.2.6 Exhaust warning	16
1.2.7 Flying Debris	17
1.2.8 Agricultural Chemicals	17
1.3 Travel on Public Roads	18
1.4 Maintenance	20
1.4.1 General maintenance information.....	20
1.4.2 Fire prevention and first aid	21
1.4.3 High pressure leaks	22
1.4.4 Tire safety	23
1.4.5 Replacement parts	23
1.5 Wing lock pins	24
1.5.1 Install the wing lock pins	24
1.5.2 Remove the wing lock pins	25
1.6 Toolbar locks	25
1.6.1 Lock the toolbar locks	25
1.6.2 Unlock the toolbar locks.....	28
1.7 Hydraulic lock-out valves	30
1.8 Marker Lamps	31
1.9 Safety and informational signs	32
1.9.1 Safety sign overview	32
1.9.2 Maximum speed sign	33
1.9.3 General safety alert hazard.....	33
1.9.4 General safety alert hazard.....	33
1.9.5 Negative tongue weight hazard	33
1.9.6 Hydraulic fluid injection hazard	34
1.9.7 Loss of machine control hazard	34
1.9.8 Chemical ingestion hazard.....	34
1.9.9 General safety alert hazard.....	34
1.9.10 Crushing Hazard	35
1.9.11 Crushing Hazard	35
1.9.12 Electrical shock hazard	35
1.9.13 Transporting hazard	35
1.9.14 Fall off hazard	36
1.9.15 Restrictor fitting	36
1.9.16 Pinch hazard	36

1.9.17 Flying objects hazard	36
1.9.18 Crushing hazard	37
1.9.19 Do not step hazard	37
1.9.20 Explosion hazard	37
1.9.21 Seed depth collar chart	37
1.9.22 Hopper capacity	38
1.9.23 Hopper capacity	38
1.9.24 Hydraulic lock-out valve	38
1.9.25 Plenum hydraulic valve	38
1.9.26 Reflector yellow	39
1.9.27 Reflector red	39
1.9.28 Reflector orange	39
1.9.29 SMV emblem	39
1.9.30 U.S. patents – A35911	40
1.9.31 Patent pending – A35495	40
2 Introduction	41
2.1 Introduction	43
2.1.1 Units of measurement	43
2.1.2 Replacement parts	43
2.1.3 Intended use	43
2.1.4 Proper disposal of waste	43
2.2 Machine identification	45
2.2.1 Serial number plate	45
2.2.2 Serial number description	45
2.3 Narrow-transport drill	47
2.4 Major components	48
2.5 Operator manual storage	50
3 Operation	51
3.1 Ladder and platform	53
3.2 Product hopper lids	54
3.3 Hydraulic jack	55
3.4 ISOBUS Harness Connector	56
3.5 Connect the machine to the tractor	57
3.6 Disconnect the machine from the tractor	59
3.7 Hydraulic systems	62
3.7.1 Drill to tractor hydraulic couplers	62
3.7.2 Bleed the air from the hydraulic lift system	62
3.7.3 Bleed the air from the hydraulic fold system	63
3.8 Frame height cylinder phasing	65
3.8.1 Put the frame height cylinders in phase	65
3.9 Blower	66
3.9.1 Blower speed	66
3.10 Meters	67
3.10.1 Change the metering wheels	67
3.10.2 Meter latches	67
3.10.3 Cleanout tray latches	68
3.10.4 Meter shaft adjustment	68
3.11 Plenum operation	69
3.11.1 Lower the plenum for service and calibration	69
3.11.2 Clean out the plenum	69

3.12 Wireless blockage monitor	70
3.13 Prepare the machine for transport	71
3.14 Prepare the machine for seeding	73
3.15 Level the wings to the center frame	75
3.16 Single-disc opener	77
3.16.1 Adjust the cast boot	77
3.16.2 Opening disc scraper adjustment	77
3.16.2.1 Adjusting the opening disc scraper	77
3.16.3 Fertilizer bander attachment	78
3.16.3.1 Adjusting fertilizer bander depth	78
3.16.4 Opening disc offset	81
3.16.4.1 Setting opening disc offset.....	81
3.16.5 Packing tires.....	81
3.16.6 Seed depth.....	82
3.16.6.1 Check the seed depth	82
3.16.6.2 Seed depth collar sequences	83
3.16.6.3 Initial seed depth collar sequences.....	83
3.16.6.4 Adjust the seed depth	84
3.17 Double-disc opener	85
3.17.1 Seed depth adjustment	85
3.17.2 Opener down pressure	85
3.17.2.1 Adjust the opener down pressure	85
3.17.3 Soil firming device adjustment	86
3.17.4 Rigid scraper adjustment	86
3.17.5 Opener blade pinch point.....	86
3.17.5.1 Check for a loose pinch point	86
3.17.5.2 Check for a tight pinch point	87
3.17.5.3 Add or remove opener shims.....	87
3.18 Toolbar down pressure	88
3.19 Turn the machine at the edge of a field	89
3.20 Software information	90
3.20.1 Software icon descriptions	90
3.20.2 Main work screen	91
3.21 System information	94
3.21.1 Terminal information	94
3.21.2 Implement software identification.....	94
3.21.3 Master switch	94
3.21.3.1 External master switch.....	95
3.21.3.2 Terminal master switch	95
3.21.4 Virtual switch box	95
3.22 Implement setup	97
3.22.1 Change the implement settings	97
3.22.2 Calibrate a drill section.....	97
3.22.3 Set the down pressure	98
3.22.4 Set the product rate	99
3.22.5 Load the bins.....	100
3.23 Totals	102
3.24 Maintenance	103
4 Maintenance	105
4.1 Lubrication points	107
4.1.1 Lubrication and maintenance chart.....	107
4.1.2 Lubrication fitting locations.....	108

4.2 Service the wheel bearings	112
4.3 Storage	113
4.3.1 Prepare the machine for storage	113
4.3.2 Prevent corrosion of extended hydraulic cylinders	114
4.3.3 Remove the machine from storage.....	114
5 Trouble shooting	115
5.1 Troubleshooting	117
6 Specifications	123
6.1 Specifications	125
6.2 Transport dimensions	126
6.3 Minimum tow vehicle weight	127
6.4 Maximum transport speed	128
6.5 Lubrication specifications	129
6.6 Frame and rear hitch tire air pressure	130
6.7 SAE fastener torque specifications	131
6.8 Torque specifications for hydraulic tubes and fittings	132
6.9 Torque specifications for O-ring boss plugs, adjustable fitting lock nuts and JIC-37 seats	133
7 Accessories	135
7.1 Fertilizer bander attachment	137
7.1.1 Adjusting fertilizer bander depth	137
8 Assembly	139
8.1 Prepare for assembly	141
8.1.1 Service parts	141
8.2 Assemble the cast boot	142
8.3 Checklists	143
8.3.1 Pre-delivery checklist	143
8.3.2 Delivery checklist	143
9 Index	145

1 Safety

1.1 Introduction	11
1.1.1 Safety alert symbol	11
1.1.2 Safety messages	11
1.1.3 Information messages	11
1.1.4 Safety signs	11
1.1.5 A word to the operator	12
1.1.6 This manual	13
1.2 Operation	14
1.2.1 Prepare for operation	14
1.2.2 General Information	14
1.2.3 Personal Protective Equipment	15
1.2.4 Seat Instructions	15
1.2.5 Shields and Guards	16
1.2.6 Exhaust warning	16
1.2.7 Flying Debris	17
1.2.8 Agricultural Chemicals	17
1.3 Travel on Public Roads	18
1.4 Maintenance	20
1.4.1 General maintenance information	20
1.4.2 Fire prevention and first aid	21
1.4.3 High pressure leaks	22
1.4.4 Tire safety	23
1.4.5 Replacement parts	23
1.5 Wing lock pins	24
1.5.1 Install the wing lock pins	24
1.5.2 Remove the wing lock pins	25
1.6 Toolbar locks	27
1.6.1 Lock the toolbar locks	27
1.6.2 Unlock the toolbar locks	28
1.7 Hydraulic lock-out valves	30
1.8 Marker Lamps	31
1.9 Safety and informational signs	32
1.9.1 Safety sign overview	32
1.9.2 Maximum speed sign	33
1.9.3 General safety alert hazard	33
1.9.4 General safety alert hazard	33
1.9.5 Negative tongue weight hazard	33
1.9.6 Hydraulic fluid injection hazard	34
1.9.7 Loss of machine control hazard	34
1.9.8 Chemical ingestion hazard	34
1.9.9 General safety alert hazard	34
1.9.10 Crushing Hazard	35
1.9.11 Crushing Hazard	35
1.9.12 Electrical shock hazard	35
1.9.13 Transporting hazard	35
1.9.14 Fall off hazard	36
1.9.15 Restrictor fitting	36
1.9.16 Pinch hazard	36
1.9.17 Flying objects hazard	36

1.9.18 Crushing hazard.....	37
1.9.19 Do not step hazard.....	37
1.9.20 Explosion hazard	37
1.9.21 Seed depth collar chart.....	37
1.9.22 Hopper capacity	38
1.9.23 Hopper capacity	38
1.9.24 Hydraulic lock-out valve	38
1.9.25 Plenum hydraulic valve	38
1.9.26 Reflector yellow	39
1.9.27 Reflector red.....	39
1.9.28 Reflector orange	39
1.9.29 SMV emblem.....	39
1.9.30 U.S. patents – A35911.....	40
1.9.31 Patent pending – A35495	40

1.1 Introduction

1.1.1 Safety symbol

The safety symbol tells you about a potentially hazardous area!

Look for the safety symbol in this manual and on the machine. The safety symbols tell you that there is important safety instructions in the manual.




Fig. 1

1.1.2 Safety messages

The words DANGER, WARNING or CAUTION are used with the safety symbol. Learn these safety messages and obey the recommended precautions and safety instructions.



DANGER:
If you do not obey the recommended precautions and safety instructions, **DEATH OR INJURY** will occur.



WARNING:
If you do not obey the recommended precautions and safety instructions, **DEATH OR INJURY** can occur.



CAUTION:
If you do not obey the recommended precautions and safety instructions, **INJURY** can possibly occur.



Fig. 2

1.1.3 Information messages

The words important and note are not related to personal safety, and are used to give information about the operation and servicing of the machine.

IMPORTANT: Identifies special instructions or procedures which, if not followed, can cause damage to the machine, the process, or the area around the machine.

NOTE: Information to make procedures easier.

1.1.4 Safety signs



WARNING:
Do not remove the safety signs. Replace safety signs that you cannot read, are damaged, or are missing.

Clean the machine surface with a weak soap and water solution before you replace the safety signs. Replacement safety signs are available from your dealer.

1. Safety

Always make sure that safety signs are in the correct locations and that you can read the safety signs. Illustrations of safety sign locations are in this section.

Keep the safety signs clean. If necessary, use a weak soap and water solution.

1.1.5 A word to the operator

It is your responsibility to read and understand the safety section in this manual and the manual for all implements before you operate this machine. You are responsible for your safety. Good safety procedures prevent injury to you and the persons around you.

Make the information in the safety section of this manual a part of your safety procedure. This safety section is written only for this type of machine. Safety is your responsibility. You can prevent injury and death.

This safety section gives basic safety examples that can occur during the operation and maintenance of your machine. This safety section is not a replacement for safety instruction in other sections of this manual.

Injury or death can occur if the safety instruction is not obeyed.

Learn how to operate the machine and how to use the controls correctly.

Do not operate the machine if you do not know how to operate the machine. Do not let persons operate the machine that do not know how to operate the machine.

Follow all safety instructions in the manuals and on the safety signs on the machine, the implements, and the attachments.

Use only approved attachments and implements.

Make sure that your machine has the correct equipment that is necessary by the local regulations.




Fig. 3



WARNING:

Do not use alcohol or drugs that can have an effect on alertness or coordination. If you use prescription or 'over the counter' drugs, get medical advice about the safe operation of machines.



CAUTION:

If attachments or implements used with this machine have a different operator manual, see that operator manual for other important safety instructions.

1.1.6 This manual

This manual covers general safety instructions for this machine. Keep this manual with the machine.

Right and left, as used in this manual, are given as if you are in the operator seat.

The photos, illustrations, and data used in this manual were up to date when published, but in-line production changes can make your machine have small differences. The manufacturer reserves the right to redesign and change the machine as necessary without notification.



WARNING:

In some of the illustrations and photos used in this manual, shields or guards are removed. Operate the machine only with all shields and guards in the correct installed positions. If the removal of shields or guards is necessary to make a repair, they must be installed before operation.

1.2 Operation

1.2.1 Prepare for operation

Read and understand all operation instructions and precautions in this manual before you operate the machine or do the servicing.

Make sure that you know and understand the positions and operations of all controls. Make sure that all controls are in neutral and that the parking brake is applied before you start the machine.

Make sure that all persons are away from your area of work before you start and operate the machine. Examine and learn the controls in an area that is clear of persons and obstacles before you start work. Know the machine dimensions and make sure that you have sufficient space available to operate the machine. Do not operate the machine at high speeds in crowded areas.

It is important to know and use the correct procedures when you do work around and operate the machine. Do not let children or unqualified persons operate the machine. Keep others, especially children, away from your area of work. Do not let others ride on the machine.

Make sure that the machine is in good condition for operation. Refer to the operator manual. Make sure that the machine has the correct equipment required by local regulations.

All equipment has a limit. Make sure you understand the speed, brakes, steering, stability and load characteristics of this machine and the tractor before you start.

1.2.2 General information

When parking, park the machine and the tractor on a solid level surface. put all controls in neutral and apply the tractor park brake. Stop the tractor engine and take the key with you.

Make sure the tractor and implement are in the proper operating condition according to the operator manuals. Make sure the tractor brakes and the machine brakes are adjusted correctly.

The tractor must have enough weight and braking capacity, especially when operating on roads and terrain that is not even. Use a tractor of recommended size and weight to tow the machine.

Tractor must be equipped with rollover protective structure (ROPS) and a seat belt. Use seat belt during operation.

Do not dismount from moving machinery.

Always operate the machine with the terminal turned on.

Never start the tractor with the PTO engaged or terminal turned on.

Stay off slopes too steep for operation.

Where possible avoid operating the machine near ditches, embankments, and holes. Reduce ground speed when operating on rough, slippery, or muddy surfaces and when turning or crossing slopes.

Be aware of the size of the machine and have enough space available to allow for operation.





Fig. 4

Always lower the machine when not in use and relieve the pressure in the hoses and cylinders.

Do not stand between the tractor and the implement to install the hitch pin when the tractor engine is running.

Avoid contact with electrical power lines. Contact with electrical power lines can cause electrical shock, resulting in very serious injury or death.




CMCHE0110036401

Fig. 5

1.2.3 Personal protective equipment

Put on all personal protective equipment (PPE) and protective clothes that are supplied to you or that are necessary for the conditions and by applicable laws. PPE includes equipment to prevent injury to your eyes, lungs, ears, head, hands and feet.

Always keep hands, feet, hair, and your clothes away from parts that move. Do not put on loose clothing, jewelry, watches, or other items that can tangle in parts that move. Tie up long hair that can also tangle in moving parts.



CMCHE0110035501

Fig. 6

1.2.4 Seat instructions


Put on the seat belt before you operate the machine. Always sit in the seat and have the seat belt on while you operate the machine. Replace the seat belts when they become worn or broken.

Do not use a seat belt loosely. Make sure that there is some tension on the seat belt. Do not wear the seat belt in a twisted condition or pinched between the structural parts of the seat.

Put on the seat belt if the instructional seat is used. Use the instructional seat only to train new operators or to find a problem. The instructional seat is only for short periods of use.

Do not let children use the instructional seat or be in the cab. Do not let other persons use the instructional seat or be in the cab.

Drive the machine at slower speed and on level ground when the instructional seat is used. Do not



CMCHE0110035601

Fig. 7

1. Safety

start, stop, or turn quickly when the instructional seat is used. Do not drive on highways or public roads when the instructional seat is used.

1.2.5 Shield and guards



WARNING: Entanglement hazard. Belts and components that rotate.

Severe personal injury or death can occur.

Do not open, remove, or put your hand behind shields if the engine is running. Stop the machine before doing service to the machine.




Fig. 8

All shields and guards must be in the correct position and in good condition. Keep away from the components that rotate.



DANGER: Entanglement hazard. Rotating components.

Severe personal injury or death can occur.

Do not make adjustments or repairs to components while they are moving. Stop the machine before doing service to the machine.

Do not operate the machine with the drive shaft shields open or removed.

Keep away from the components that turn.

Make sure guards that turn are free.



Fig. 9

1.2.6 Exhaust warning



WARNING: Inhalation hazard. Exhaust gases.

Death or serious illness can occur.

Do not operate the engine in a closed building unless the exhaust is ventilated to the outside.

Do not tamper with or modify the exhaust system with unapproved extensions.




Fig. 10

1.2.7 Flying debris



WARNING:
Be careful when you operate along the side of a road or structures. Rocks and other materials can be thrown from the machine during operation and can cause injury.

Stay away from the machine during operation. Some materials can be thrown from the machine during operation and cause injury.



CMCHE0110038001

Fig. 11

1.2.8 Agricultural chemicals

Agricultural chemicals are very dangerous. Incorrect procedures with fertilizer, fungicides, herbicides, insecticides and pesticides can cause injuries to plants, animals, soil and other persons property.

Always read and follow all manufacturers instructions before you open chemical containers.

Read and follow instructions each time you use a chemical.

Use the same precautions when you do adjustments, do servicing, clean or store the machine as used when you put chemicals into the hoppers or tanks.

Tell all persons who are near chemicals of the possible dangerous results and the safety precautions that are necessary.

Stay upwind and away from smoke from a chemical fire.

Keep or discard all chemicals that are not used as specified by the chemical manufacturer.

1.3 Travel on public roads

Make sure you understand the speed, brakes, steering, stability, and load characteristics of this machine before you travel on public roads.

Use good judgment when traveling on public roads. Maintain complete control of the machine at all times. Never coast down hills.

The maximum speed of farm equipment is governed by local regulations. Adjust travel speed to maintain control at all times.

Familiarize yourself with and obey all road regulations that apply to your machine. Consult your local law enforcement agency for local regulations regarding movement of farm equipment on public roads. Use head lamps, flashing warning lamps, tail lamps and turn signals, day and night, unless prohibited by local law.

Make sure all the flashers are operating prior to driving on the road. Make sure reflectors are correctly installed, in good condition, and wiped clean. Make sure the Slow Moving Vehicle (SMV) emblem is clean, visible, and correctly mounted on the rear of the machine.

Lock brake pedals together (if equipped with dual brake pedals) so both wheel brakes will be applied at the same time.

Raise implements to transport position and lock in place. Place all implements into narrowest transport configuration.

Disengage the power take-off and differential lock.

With towed implements, use a proper hitch pin with a clip retainer and safety transport chain.

Use a safety transport chain with a strength rating equal to or more than the gross weight of the towed machine.

Connect the safety transport chain to the tractor drawbar and use a retainer on the hitch pin.

Supply only enough slack in the safety transport chain to permit turning.

Do not use the safety transport chain as a tow chain for towing.

Be aware of other traffic on the road. Keep well over to your own side of the road and pull over, whenever possible, to let faster traffic pass.

Be aware of the overall width, length, height, and weight of the machine. Be careful when transporting the machine on narrow roads and across narrow bridges.




Fig. 12

CMCHE0110038101

Watch for overhead wires and other obstructions. Avoid contact with electrical power lines. Contact with electrical power lines can cause electrical shock, resulting in very serious injury or death.




Fig. 13

1.4 Maintenance

1.4.1 General maintenance information

Before you do maintenance, lubricate, do servicing, clean, or make adjustments:

- Park the machine on a solid, level surface.
- Make sure that all the controls are in the neutral position and apply the parking brake.
- Make sure that the machine and the attachments are lowered to the ground.
- Stop the engine and take the key with you.
- Look and Listen! Make sure that all parts that move are stopped.
- Put chocks in front of and behind the wheels of the machine before you do work on or below the machine.




Fig. 14

Stay near the machine when the tractor is in operation.

Know the dimensions and the weights of parts when you do the servicing. Do not stand below or near a part while it is moved with a hoist or other lift equipment.

After you do work on the machine, remove all tools from the machine.

Make sure that electrical connectors are clean before you connect them.

Do a check for loose, broken, missing, or damaged parts. Make sure that the machine is in good repair. Make sure that all guards and shields are in position.

Always lift the machine, stop the tractor engine, apply the parking brake, move to the park position (or neutral) remove the key and install the cylinder stops channels before you do work around the machine.

Do not go below the machine. If you must go below the machine, make sure that the machine is blocked and the cylinder lockup channels are in position.

Do not do the servicing, examine or adjust chains or belts while the engine is in operation.




Fig. 15

Do not operate the machine with the drive shaft shields open or removed. Entanglement in drive shafts that rotate can cause injury or death.

Stay clear of components that rotate.

Make sure that guards that rotate can rotate freely.

A loose yoke can come off a shaft and result in injury to persons or damage to the machine.

When you install a quick disconnect yoke, the spring activated locking pins must move freely and be in the groove on the shaft. Pull on the driveline to make sure that the quick disconnect yoke can not be pulled off the shaft.

Remove spilled oil, antifreeze or fuel immediately from the steps, platform, and other access areas.

Keep all access areas clean of unwanted materials.



CMCHE0110036601

Fig. 16



CMCHE0110119801

Fig. 17

1.4.2 Fire prevention and first aid

Be prepared for emergencies.

Keep a first aid kit available for use on small cuts and scratches.

Keep one or more fire extinguishers of the correct type. Examine fire extinguishers regularly as stated by the manufacturer. Make sure that the fire extinguishers are charged and in operating condition.

Crop material is flammable, there is a risk of fire. Use a water type fire extinguisher or other water source for a fire in crop.

For fires in material other than crop, such as oil or electrical components, use a dry chemical fire extinguisher with an ABC rating.

Keep fire extinguishers easy to access where fires can occur.

Frequently remove crop material from the machine and examine for components that are too hot. Do checks on the machine each day for noises that are not usual. Unusual noises can indicate a worn out component that can cause too much heat.

If flame cutting, welding, arc welding, or grinding is to be done on the machine or attachments, clear



CMCHE0110035701

Fig. 18

1. Safety

crop material and unwanted material from around the area. Make sure that the area below the work area is clear of flammable material because falling molten metal and sparks can cause ignition in the material.

If fire occurs, move upwind and away from the smoke from the fire.



Fig. 19

1.4.3 High pressure leaks



WARNING: Hydraulic fluid under pressure can penetrate the skin or eyes.

Serious personal injury, blindness, or death can occur.

Relieve the pressure from the system or component before disconnecting components. Wear personal protective gear while working on the machine or equipment. Use a piece of cardboard to check for leaks. Never use your hand.

Fluid that leaks from the hydraulic system or the fuel injection system is high pressure and is not easily seen. The fluid can go into the skin causing injury.

Fluid that is injected into the skin must be surgically removed immediately. If not removed immediately, infection and reaction can occur. Go immediately to a physician who knows about this type of injury.

Use a piece of cardboard or wood to look for possible leaks. Do not use your bare hand. Wear leather gloves for hand protection and safety goggles for eye protection.

Remove all pressure before you loosen hydraulic lines. Lower equipment in the up position, close the accumulator valve, and stop the engine. Tighten all connections before you apply pressure.



Fig. 20




Fig. 21

1.4.4 Tire safety

Examine tires for cuts, bulges, and correct pressure. Replace worn or damaged tires. When tire service is needed, have a qualified tire mechanic service the tire. Tire changing can be very hazardous and must be done by qualified tire mechanic using proper tools and equipment.

Tire explosion and/or serious injury can result from over inflation. Do not exceed the tire inflation pressures.

Do not inflate a tire that is seriously under inflated or has been run flat. Have the tire examined by qualified tire mechanic.

Do not weld on the rim when a tire is installed. Welding will make an air/gas mixture that can cause an explosion and burn with high temperatures. This hazard applies to all tires, inflated or deflated. Removing air or breaking the bead is not enough. The tire must be completely removed from the rim prior to welding.

When preparing a calcium chloride solution for fluid ballast the tractor tires, never pour water onto the calcium chloride. A chlorine gas can be generated which is poisonous and explosive. This can be avoided by slowly adding calcium chloride flakes to water and stirring until they are dissolved.

When seating tire beads onto rims, never exceed 35 psi (2.4 bar) or the maximum inflation pressure specified on the tire. Inflation beyond this maximum pressure may break the bead, or even the rim, with explosive force.



Fig. 22

CMCHE0110039401

1.4.5 Replacement parts

Where replacement parts are necessary for machine maintenance and servicing, you must use original equipment replacement parts.

The manufacturer will not accept responsibility for installation of unapproved parts and/or accessories and damages as a result of their usage.




Fig. 23

CMCHE0110039501

1.5 Wing lock pins

The machine is equipped with two wing lock pins. The wing lock pins are used to lock the wings in the raised or folded position. Install the wing lock pins when transporting or servicing the drill.

When unlocking the wings, keep the wing lock pins (1) and wire lock pins in the brackets (2) located on the main frame (3). The wing lock brackets are located at the hinge points of each wing.




Fig. 24

1.5.1 Install the wing lock pins

Install the wing lock pins when the machine is to be transported or serviced with the wing in the raised or folded position.

Procedure

1. Use the tractor hydraulics to fully lift the wings of the machine.
2. Stop the engine, set the tractor park brake, and take the ignition key with you.
3. Remove the wire lock pin (2) from the end of the wing lock pin (1).
4. Remove the wing lock pin (1) from the storage bracket (3).




Fig. 25

5. Install the wing lock pin (1) through the holes in the wing lock brackets (3).
6. Install the wire lock pin (2) in the end of the wing lock pin.




Fig. 26

7. Use the same procedure to install the remaining wing lock pins in the wing lock brackets on the remaining hinge points.

1.5.2 Remove the wing lock pins

Remove the wing lock pins before lowering the wings of the machine.

Procedure

1. Use the tractor hydraulics to remove any load from the wing lock pins by completely raising the wings.
2. Stop the engine, set the tractor park brake, and take the ignition key with you.
3. Remove the wire lock pin (2) from the end of the wing lock pin (1).
4. Remove the wing lock pin (1) from the wing lock brackets (3).




Fig. 27

5. Install the wing lock pin (1) in the storage bracket (3) on the main frame of the machine.
6. Install the wire lock pin (2) in the end of the wing lock pin (1).




Fig. 28

7. Remove the remaining wing lock pins from the wing lock brackets of the remaining hinge points.

1. *Safety*

8. Use the tractor hydraulics to lower the wings to the ground.

1.6 Toolbar locks

Each toolbar has a toolbar lock (1). A toolbar lock tool is used turn the lock in the slot (2) and lock the toolbar. The toolbar locks are used to lock the toolbars in the lifted position. Engage the toolbar locks when transporting the drill or servicing the toolbars.




Fig. 29

1.6.1 Lock the toolbar locks

Lock the toolbars before transporting the drill or servicing the toolbars.

Procedure

1. Use the tractor hydraulics to fully lift the toolbars.
2. Stop the engine, set the tractor park brake, and take the ignition key with you.
3. Remove the toolbar lock tool (1) from the storage position (2). Remove the wire lock pin (3) that attaches the toolbar lock to the light bar assembly.




Fig. 30

4. Use the toolbar lock tool to push in and turn the lock (1) clockwise to the locked position (2). The toolbar is locked when the lock is pushed in and fully turned into the slot.
5. Use the same procedure to lock the remaining toolbars on the machine.




Fig. 31

1. Safety

6. Put the toolbar lock tool (1) in the storage position (2) when complete.
7. Attach the toolbar lock tool to the light bar assembly with the wire lock pin (3).




Fig. 32

1.6.2 Unlock the toolbar locks

Unlock the toolbars before operation in the field.

Procedure

1. Use the tractor hydraulics to fully lift the toolbars to remove the load.
2. Stop the engine, set the tractor park brake, and take the ignition key with you.
3. Remove the toolbar lock tool (1) from the storage position (2). Remove the wire lock pin (3) that attaches the toolbar lock to the light bar assembly.




Fig. 33

4. Use the toolbar lock tool to push and turn the lock (1) counter-clockwise to the unlocked position (2). The toolbar is unlocked when released from the slot and extended back.
5. Use the same procedure to unlock the remaining toolbars on the drill.




Fig. 34

6. Put the toolbar lock tool (1) in the storage position (2) when complete.
7. Attach the toolbar lock tool to the light bar assembly with the wire lock pin (3).




Fig. 35

1.7 Hydraulic lock-out valves

The hydraulic lock-out valve is on the front of the frame, on the left-hand side of the front hitch.

The toolbar lock-out valve (1) is installed on all drills. The toolbar lock-out valve is used to hydraulically lock the toolbars in the transport or raised position.



WARNING:

The toolbars can drop to the ground when the toolbar lock-out valve is opened. Make sure the area below the toolbars is clear of people and obstructions before opening the toolbar lock-out valve.




Fig. 36

Move the valve handle so the handle is parallel to the frame to put the lock-out valve in the open position (1). In the open position hydraulic pressure can flow through the valve.

Move the valve handle up to put the lock-out valve in the closed position (2). In the closed position the hydraulic pressure will not flow through the valve.

IMPORTANT: *Open the valve when seeding and close the valve when transporting the drill.*




Fig. 37

1.8 Marker lamps

The machine has marker lamps that must be used when moving the machine on roads.

The machine is equipped with two amber lamps (1) located at the outside edges of the machine.

The machine is equipped with two red lamps (2) located toward the center of the machine.




Fig. 38

1.9.2 Maximum speed sign

Maximum speed sign	
 <p>TLFBEO110454901</p>	<p>Maximum speed sign</p> <p>The maximum speed instructional sign displays the maximum speed the machine can be transported.</p>

1.9.3 General safety alert hazard

General safety alert hazard	
 <p>TLFBEO110389701</p>	<p>General safety alert</p> <p>Read and understand the operator manual before operating the machine.</p>

1.9.4 General safety alert hazard

General safety alert hazard	
 <p>TLFBEO110389601</p>	<p>General safety alert</p> <p>Shut off the engine and remove the key before performing maintenance or repair work.</p>

1.9.5 Negative tongue weight hazard

Negative tongue weight hazard	
 <p>TLFBEO110389501</p>	<p>Negative tongue weight will cause immediate elevation of the tongue</p> <p>Stay clear of the tongue when disconnecting the implement from the tractor. Read the operator manual for safety information and operating instructions before operating the machine.</p>


1.9.6 Hydraulic fluid injection hazard

Hydraulic fluid injection hazard	
 <p>TLFBE0110389901</p>	<p>Injection hazard into skin - escaping fluid is under high pressure</p> <p>Shut off engine, remove the key, and relieve pressure before performing maintenance or repair work. Refer to the operator manual for proper service procedures.</p>

1.9.7 Loss of machine control hazard

Loss of machine control hazard	
 <p>TLFBE0110389401</p>	<p>Loss of machine control</p> <p>Install the safety chains when attaching the machine to the tractor. Read the operator manual for safety information and operating instructions before operating the machine.</p>

1.9.8 Chemical ingestion hazard

Chemical ingestion hazard	
 <p>TLFBE0110454501</p>	<p>Dust/fumes inhalation hazard - risk of asphyxiation</p> <p>Refer to the Operator's Manual for safety information and operating instructions and chemical manufacturers instructions before operating the machine.</p>

1.9.9 General safety alert hazard

General safety alert hazard	
 <p>TLFBE0110454401</p>	<p>General safety alert</p> <p>Watch your step</p>


1.9.10 Crushing hazard

Crushing hazard	
 <p>TLFB E0110454601</p>	<p>Crushing hazard from lowering or falling wing</p> <p>Stay clear of this area while engine and machine are operating. For service work, install the wing lock pins before getting under wing.</p>

1.9.11 Crushing hazard

Crushing hazard	
 <p>TLFB E0110390101</p>	<p>Crushing hazard</p> <p>Stay clear of this area while engine and machine are operating. For service work, install the lock pins before getting under the machine.</p>

1.9.12 Electrical shock hazard

Electrical shock hazard	
 <p>TLFB E0110389801</p>	<p>Electrical shock hazard - risk of personal injury and component damage</p> <p>Keep sufficient distance away from electrical power lines.</p>

1.9.13 Transporting hazard

Transporting hazard	
 <p>TLFB E0110454701</p>	<p>Transporting hazard</p> <p>Install wing fold lock pins before transporting. To prevent machine damage, remove the pins before unfolding the machine.</p>

1.9.14 Fall off hazard

Fall off hazard	
 <p>TLFBE0110455001</p>	<p>Fall off hazard Do not ride on this machine.</p>

1.9.15 Restrictor fitting

Restrictor fitting	
 <p>TLFBE0110454301</p>	<p>Risk of injury and component damage Be sure to install restrictor when servicing or assembling.</p>

1.9.16 Pinch hazard

Pinch hazard	
 <p>TLFBE0110454801</p>	<p>Pinch hazard - risk of personal injury Keep hands clear.</p>

1.9.17 Flying objects hazard

Flying objects hazard	
 <p>TLFBE0110455101</p>	<p>Flying objects hazard - risk of personal injury Stop fan before lowering plenum for calibration or service. Stay clear when machine is operating.</p>

1.9.18 Crushing hazard

Crushing hazard	
 <p>TLFBE0110455301</p>	<p>Keep foot clear - risk of personal injury Keep foot clear while operating jack.</p>

1.9.19 Do not step hazard

Do not step hazard	
 <p>TLFBE0110455701</p>	<p>Do not step on this surface.</p>

1.9.20 Explosion hazard

Explosion hazard	
 <p>TLFBE0110455201</p>	<p>Explosion hazard - rotor is turning at high speeds Shut off engine, remove key and relieve pressure before performing maintenance or repair work. See service manual for proper repair procedures.</p>

1.9.21 Seed depth collar chart

Seed depth collar chart	
 <p>TLFBE0110455401</p>	<p>Seed depth collar chart</p>


1.9.22 Hopper capacity

Hopper capacity	
 <p>TLFBE0110455501</p>	<p>Hopper capacity 70 bu (2467 L)</p>


1.9.23 Hopper capacity

Hopper capacity	
 <p>TLFBE0110455601</p>	<p>Hopper capacity 105 bu (3700 L)</p>

1.9.24 Hydraulic lock-out valve

Hydraulic lock-out valve	
 <p>TLFBE0110516901</p>	<p>Hydraulic lock-out valve Locked/Unlocked</p>

1.9.25 Plenum hydraulic valve

Plenum hydraulic valve	
 <p>TLFBE0110517001</p>	<p>Plenum hydraulic valve</p>

1.9.26 Reflector yellow

Reflector, yellow	
 TLFBE0110390401	Reflector, yellow

1.9.27 Reflector red

Reflector, red	
 TLFBE0110390201	Reflector, red

1.9.28 Reflector orange

Reflector, orange	
 TLFBE0110390301	Reflector, orange

1.9.29 SMV emblem

SMV emblem	
 TLFBE0110390501	SMV (slow moving vehicle) emblem

1.9.30 U.S. patents - A35911

Hopper capacity	
<div data-bbox="363 361 597 426" style="border: 1px solid black; padding: 5px; text-align: center;">U.S. Patents 7,104,206 B1 7,216,596 B2</div> <p data-bbox="462 491 597 512" style="text-align: center;">TLGBE0110197801</p>	<p>U.S. patents</p>

1.9.31 Patent pending - A35495

Hopper capacity	
<div data-bbox="363 772 597 831" style="border: 1px solid black; padding: 5px; text-align: center;">PATENT PENDING US AND INTERNATIONAL</div> <p data-bbox="462 905 597 926" style="text-align: center;">TLGBE0110197701</p>	<p>Patent pending</p>

2 Introduction

2.1 Introduction	43
2.1.1 Units of measurement.....	43
2.1.2 Replacement parts.....	43
2.1.3 Intended use.....	43
2.1.4 Proper disposal of waste.....	43
2.2 Machine identification	45
2.2.1 Serial number plate.....	45
2.2.2 Serial number description.....	45
2.3 Narrow-transport drill	47
2.4 Major components	48
2.5 Operator manual storage	50

2.1 Introduction



CAUTION:

In some of the illustrations used in this Operator Manual, panels or guards may have been removed for clarity. Never operate the machine with these panels and guards removed. If the removal of a shield is necessary to make a repair, it must be replaced before operation.



CAUTION:

Read this book in its entirety prior to operating machine. Use only genuine replacement parts for repairs and/or replacement.

This manual gives the operator the proper instructions needed for operation and maintenance. Read, understand, and follow these instructions for best machine performance and life. With proper maintenance and operation procedures, the machine will have better overall performance. Use normally available tools for maintenance on this machine.

All operators must read and understand this manual before operating this machine. Where possible, operators who have not operated the machine must receive instruction from an operator who has operated this machine. Your dealer can give instruction in machine operation. Keep this manual with the machine for future reference. If the original manual is damaged, order a replacement from your dealer.

See your dealer for any service problems and adjustments. The dealer is equipped for all service work and to help with specific applications of the machine in local conditions.

Left-hand and right-hand are determined by facing the direction the machine will travel when in use.

2.1.1 Units of measurement

Measurements are given in US units followed by the equivalent in metric units. Hardware sizes are given in millimeters for metric hardware and inches for US hardware.

2.1.2 Replacement parts

To receive your parts quickly, have the following information:

- Correct part description and part number
- Model number of the machine
- Serial number of the machine

2.1.3 Intended use

This machine is designed solely for use in customary agricultural operations.

Do not use this machine for any application or purpose other than those described in this manual. The manufacturer accepts no liability for damage or injury resulting from misuse of this machine.

Compliance with the conditions of operation, service and repair as specified by the manufacturer constitute essential elements for the intended use of this machine.

This machine should be operated, serviced and repaired only by qualified persons familiar with its characteristics and familiar with the relevant safety rules and procedures.

All generally recognized safety regulations and road traffic regulations must be obeyed at all times.

Any unauthorized modifications performed on this machine will relieve the manufacturer of all liability for any resulting damage or injury.

2.1.3.1 Proper disposal of waste

Improper disposal of waste can pollute the environment and ecology. A few examples of potentially harmful equipment waste can include, but not limited to, items such as oil, fuel, coolant, brake fluid, filters, battery chemicals, tires, etc.

2. Introduction

Use leak proof containers when draining fluids. Do not use food or beverage containers to collect waste fluids, as food or beverage container(s) may mislead someone into drinking from them.

Do not pour or spill waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire with local environmental or recycling center on the proper way to recycle or dispose waste.

2.1.4 Proper disposal of waste

Improper disposal of waste can pollute the environment and ecology. A few examples of potentially harmful equipment waste can include, but not limited to, items such as oil, fuel, coolant, brake fluid, filters, battery chemicals, tires, etc.

Use leak proof containers when draining fluids. Do not use food or beverage containers to collect waste fluids, as food or beverage container(s) may mislead someone into drinking from them.

Do not pour or spill waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire with local environmental or recycling center on the proper way to recycle or dispose waste.

2.2 Machine identification

Each machine is identified by a model and a serial number.

Record these numbers in the spaces given.

Give the model number and serial number to your dealer when parts or servicing are necessary.

Machine model number: _____

Machine serial number: _____

Date of delivery: _____

Dealer name: _____

Dealer address: _____


Dealer telephone number: _____

Dealer e-mail address: _____

Dealer fax number: _____

2.2.1 Serial number plate

The serial number plate (1) is located on the front of the center frame.




TLFBE0110438101

Fig. 1

2.2.2 Serial number description

Description of the serial number for model years 2017 and up.



CMCHE0110056501

Fig. 2

- (1) Beginning symbol
- (2) World manufacturer code
- (3) Brand code
- (4) Model identifier (model number)

2. Introduction

- | | |
|---|-----------------------------|
| (5) Check letter (0 or used if model identifier is five digits) | (7) Plant code |
| (6) Model year code (G = 2016, H = 2017, J = 2018, K = 2019) | (8) Family code |
| | (9) Unit number of the year |
| | (10) End symbol |

2.3 Narrow-transport drill

The narrow-transport drill is designed to seed in a range of soil conditions from no till with heavy residue to conventional till. The single disc drill can seed in these conditions without adjusting the openers. An air distribution system is used to distribute the seed to each of the openers. The drill is monitored using a display in the cab of the tractor. The drill is available with a single-disc opener or a double-disc opener. The single-disc opener is shown.




Fig. 3

2.4 Major components

The following are the major components of the machine.




Fig. 4

- | | |
|------------------|-------------------------------------|
| (1) Tongue | (3) Wing frame |
| (2) Center frame | (4) Single-disc opener packer tires |

- | | |
|--------------------------------------|-------------------------------|
| (5) Single-disc opener opening discs | (9) Wing frame support wheels |
| (6) Toolbars | (10) Hopper - two compartment |
| (7) Marker lamp bar | (11) Ladder |
| (8) Center frame support wheels | (12) Double-disc opener |

2.5 Operator manual storage

The Operator Manual is located in the container (1) on the machine.




Fig. 5

3 Operation

3.1 Ladder and platform	53
3.2 Product hopper lids	54
3.3 Hydraulic jack	55
3.4 ISOBUS Harness Connector	56
3.5 Connect the machine to the tractor	57
3.6 Disconnect the machine from the tractor	59
3.7 Hydraulic systems	62
3.7.1 Drill to tractor hydraulic couplers	62
3.7.2 Bleed the air from the hydraulic lift system	62
3.7.3 Bleed the air from the hydraulic fold system	63
3.8 Frame height cylinder phasing	65
3.8.1 Put the frame height cylinders in phase	65
3.9 Blower	66
3.9.1 Blower speed	66
3.10 Meters	67
3.10.1 Change the metering wheels	67
3.10.2 Meter latches	67
3.10.3 Cleanout tray latches	68
3.10.4 Meter shaft adjustment	68
3.11 Plenum operation	69
3.11.1 Lower the plenum for service and calibration	69
3.11.2 Clean out the plenum	69
3.12 Wireless blockage monitor	70
3.13 Prepare the machine for transport	71
3.14 Prepare the machine for seeding	73
3.15 Level the wings to the center frame	75
3.16 Single-disc opener	77
3.16.1 Adjust the cast boot	77
3.16.2 Opening disc scraper adjustment	77
3.16.2.1 Adjusting the opening disc scraper	77
3.16.3 Fertilizer bander attachment	78
3.16.3.1 Adjusting fertilizer bander depth	78
3.16.4 Opening disc offset	81
3.16.4.1 Setting opening disc offset	81
3.16.5 Packing tires	81
3.16.6 Seed depth	82
3.16.6.1 Check the seed depth	82
3.16.6.2 Seed depth collar sequences	83
3.16.6.3 Initial seed depth collar sequences	84
3.16.6.4 Adjust the seed depth	84
3.17 Double-disc opener	85
3.17.1 Seed depth adjustment	85
3.17.2 Opener down pressure	85
3.17.2.1 Adjust the opener down pressure	85
3.17.3 Soil firming device adjustment	86
3.17.4 Rigid scraper adjustment	86

3.17.5 Opener blade pinch point.....	86
3.17.5.1 Check for a loose pinch point.....	86
3.17.5.2 Check for a tight pinch point	87
3.17.5.3 Add or remove opener shims.....	87
3.18 Toolbar down pressure.....	87
3.19 Turn the machine at the edge of a field	89
3.20 Software information	90
3.20.1 Software icon descriptions	90
3.20.2 Main work screen	91
3.21 System information	94
3.21.1 Terminal information	94
3.21.2 Implement software identification.....	94
3.21.3 Master switch	94
3.21.3.1 External master switch.....	95
3.21.3.2 Terminal master switch	95
3.21.4 Virtual switch box	95
3.22 Implement setup	97
3.22.1 Change the implement settings	97
3.22.2 Calibrate a drill section.....	97
3.22.3 Set the down pressure	98
3.22.4 Set the product rate	99
3.22.5 Load the bins.....	100
3.23 Totals	102
3.24 Maintenance	103

3.1 Ladder and platform

The machine has a ladder that folds up and down for easy access to the hopper lids.

The machine has a platform with handrails around to prevent falls.

NOTE: *Do not remove the handrails.*

Only fold the ladder when the machine is stopped and on a flat, solid surface.

Put the ladder (1) in the down position for access to the hopper lids




Fig. 1

Fold the ladder (1) to the storage position before transport or operation.

NOTE: *If the ladder is down in transport or operation, it can catch the tire and cause tire and ladder damage.*




Fig. 2

3.2 Product hopper lids

The product hopper lids on the drill must be sealed to keep water out.

To open the latch, grab the end of the rod (1) and pull on the latch.




Fig. 3

Check the product hopper lids for correct adjustment and inspect the seal for damage.

To adjust the latch, loosen the four 1/4 inch bolts (1) that hold the latch, and move it up or down. The latch should be adjusted so there is slight pressure on the rod when it is secured. Tighten the four 1/4 inch bolts when finished.




Fig. 4

3.3 Hydraulic jack

The machine has a hydraulic jack (1) to lift or lower the hitch. To prevent injury or damage, only have the jack connected to the hydraulic remote when you connect or disconnect the machine.

The jack must be pinned in the upper or lower position at all times. The jack must only be unpinned when used to attach the machine to the tractor, or injury or death could result.




Fig. 5

3.4 ISOBUS Harness Connector

The machine has two connectors used to connect to the ISOBUS harness.

Front ISOBUS Connector

The front ISOBUS connector is located on the front hitch of the machine and is used to connect the machine ISOBUS to the tractor. The front ISOBUS connector is a standard nine pin connector.

Rear ISOBUS Connector

The rear ISOBUS connector (1) is located in the rear connection bulkhead and is used to connect the machine ISOBUS to a pull behind implement. The rear ISOBUS connector is a standard nine pin connector.




Fig. 6

3.5 Connect the machine to the tractor

Procedure

1. Make sure there are no people, pets, or obstructions between the tractor and the machine.

2. Use the hitch jack (1) on the front hitch of the machine to adjust the height of the hitch. Adjust the height of the hitch on the machine until the hitch on the machine is at the same height as the hitch on the tractor.

NOTE: The jack must be pinned in the upper or lower position at all times. The jack must only be unpinned when used to attach the tractor to the machine, or injury or death may result.

3. Slowly move the tractor toward the hitch of the machine. Align the hitch on the tractor with the hitch on the machine when backing.

4. Stop the tractor when the hole of the tractor hitch aligns with the hole in the machine hitch.

5. Stop the engine, set the park brake, and take the ignition key with you.

6. Install the hitch pin (1) through the holes in the tractor draw bar (2) and machine hitch (3). Install the keeper pin (4) in the hitch pin.

7. Connect the safety chains from the front hitch of the machine to the tractor.




Fig. 7

8. Retract the hitch jack (1).

9. Clean the ends of the hydraulic connections on the machine and the tractor.

10. Make the following connections between the tractor and the machine.

- Lift cylinder hydraulic hoses
- Wing cylinder hydraulic hoses
- Toolbar down pressure hydraulic hoses
- Fan hydraulic hoses
- ISO harness to the tractor
- Safety light harness




Fig. 8




Fig. 9

IMPORTANT: Connect the toolbar down pressure hydraulic hoses and wing cylinder hydraulic hoses directly to the tractor hydraulics. Aftermarket or added hydraulic connections do not supply the needed hydraulic flow to operate the machine correctly.

3. Operation

11. Start the tractor and use the tractor hydraulics to lift the frame of the machine to the highest position.
12. If the wing frames were down during storage, make sure the wing cylinders are connected to the wing frames.
13. Use the tractor hydraulics to fully lift the wing frames of the machine.
14. Stop the engine, set the park brake, and take the ignition key with you.
15. Remove the wheel chocks (1) or blocks from in front of and behind the frame support tires (2).
16. Make sure all people, pets, and obstructions are clear before moving the tractor and machine.





Fig. 10

3.6 Disconnect the machine from the tractor

NOTE: Lower the wings for storage when possible.

Procedure


1. Park the tractor and machine on a solid level surface.
2. Stop the engine, set the park brake, and take the ignition key with you.
3. Use the tractor hydraulics to lower the wings to the ground if possible.
4. Use the tractor hydraulics to fully lift the toolbars.
5. Stop the engine, set the tractor park brake, and take the ignition key with you.
6. When disconnecting the machine with the wing frames lifted, install the wing lock pins (1) and wire lock pins (2) in the wing lock brackets (3).



TLFBE0110440801

Fig. 11

7. Use the toolbar locks (1) to lock the toolbars in the locked position (2).



SEKBE0110106501

Fig. 12

3. Operation

8. Install wheel chocks (1) or blocks in front of and behind each of the frame support tires (2).




Fig. 13

9. Remove all the seed depth collars (1) from the frame height cylinders (2) and place them on the depth collar storage bracket.
10. Start the tractor. Lower the frame of the machine until the weight of the machine is off of the hitch of the tractor.




Fig. 14

11. Stop the engine, set the tractor park brake, and take the ignition key with you.
12. Install the correct seed depth collars on the frame height cylinders to take up the remaining stroke of each frame height cylinder.
13. Start the tractor. Continue to lower the frame of the machine until the seed depth collars support the weight of the frame.
14. Use the hitch jack (1) to support the front hitch of the machine.
NOTE: *The jack must be pinned in the upper or lower position at all times. The jack must only be unpinned when used to attach the tractor to the machine, or injury or death may result.*




Fig. 15

15. Disconnect the following connections from the tractor.
 - Lift cylinder hydraulic hoses
 - Wing cylinder hydraulic hoses
 - Down pressure hydraulic hoses
 - Fan hydraulic hoses
 - ISO harness to the tractor
 - Light harness

16. Install each of the hydraulic hose connections (1) in the hose support bracket (2).
17. Clean the hydraulic connections between the machine and the tractor of any dirt or hydraulic fluid.
18. Remove the transport safety chains from the tractor.




Fig. 16

19. Remove the keeper pin (1) from the hitch pin (2). Remove the hitch pin from the hitch (3) and draw bar (4).

IMPORTANT: *Make sure there are no connections between the tractor and the machine.*

20. Make sure all people and pets are clear of the tractor and machine.
21. Slowly move the tractor away from the machine.




Fig. 17

3.7 Hydraulic systems

The hydraulic system on the machine includes:

- Blower control circuit
- Downpressure circuit
- Wing fold circuit
- Depth control circuit
- Hydraulic jack

This system was designed to function under a maximum hydraulic pressure of 2900 psi (19 995 kPa).

Fan only	10cc fan motor	
Fan speed	Flow	Pressure
3000 rpm	8 gal/min (30.1 l/min)	1000 to 1500 psi (6895 to 10 342 kPa)
4000 rpm	10.5 gal/min (39.7 l/min)	1400 to 1900 psi (9653 to 13 100 kPa)
5000 rpm	13.5 gal/min (51 l/min)	1800 to 2300 psi (12 411 to 15 858 kPa)
6000 rpm	60.6 l/min (16 gal/min)	2200 to 2700 psi (15 168 to 18 616 kPa)

3.7.1 Drill to tractor hydraulic couplers

The couplers connecting the blower pressure and the return lines from the drill to the tractor are (1/2 inch) #10 ISO 5675 (Pioneer) tip couplers.

A (3/8 inch) #8 ISO 16028 (flat-face) coupler tip on the drill connects the case drain line to the tractor. The case drain line must be connected or the blower motor will be damaged. If a case drain return port is not available on your tractor, contact your dealer.

A (3/4 inch) #12 ISO 7241-1 Series A low-pressure return tip is included with all implements. The low-pressure return tip is also available through Service Parts.

If your tractor has a low-pressure port available, the low-pressure return tip can be used on the 3/4 inch blower return line. Using the low-pressure return tip can remove the pressure drop caused by the 1/2 inch Pioneer tip and the hydraulic valve of the tractor on the return side. The low-pressure return tip can also be used on the case drain line, if the 3/8 inch flat face port is not available.

Do not install a tee fitting connecting the blower return line and the blower case drain lines together. The blower case line must always be connected to a direct return to the hydraulic reservoir or blower motor failure will result.

The hydraulic line with the label pressure must be used to operate the blower. A check valve is installed in the blower circuit to protect the motor from the too much pressure in the return line and prevents cavitation during shutdown.

The couplers connecting the downpressure, wing fold, depth control circuits and hydraulic jack from the drill to the tractor are (1/2 inch) #10 ISO 5675 (Pioneer) tip couplers.

3.7.2 Bleed the air from the hydraulic lift system

Before starting the procedure



WARNING:

Leaking fluid under pressure can enter the skin causing serious injury. Release pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Wear correct hand and correct eye protection when looking for leaks. Use a piece of cardboard or paper instead of your hand. Any fluid injected into the skin can cause gangrene. The fluid must be removed by a doctor familiar with this type of injury.


WARNING:

Be careful of sweeps or blades when folded to prevent serious injury. Never keep the machine with the wings in the folded position.

To bleed the air from the hydraulic lift system, connect the machine to a tractor that is the correct size to operate the machine. See the information for minimum tow vehicle weight.

Completely bleed the hydraulic system of air when:

The lift system is filled with hydraulic oil for the first time.

Air has entered the hydraulic system through a leak or through repair of the hydraulic system.

Procedure

1. Park the machine on a flat, level surface that is large enough for the machine when unfolded.
2. Set the tractor hydraulic flow to less than 20 gal/min (75.7 L/min).
IMPORTANT: *If the hydraulic flow is set to more than 20 gal/min (75.7 L/min) the hydraulics will not operate correctly.*
3. Connect the lift system hoses to the tractor.
4. Make sure the tractor reservoir is full of the hydraulic oil required by the manufacturer. **IMPORTANT:** *Do not loosen any hydraulic fittings to bleed air from the system.*
5. Raise the machine. Continue to hold the tractor lever to let oil bypass and fill each wing lift cylinder.
6. Engage the hydraulics to remove any hydraulic transport locks if equipped.
7. Stop the engine, apply the park brake and take the key with you.
8. Remove the transport locks when all lift cylinders are fully extended.
9. Lower the unit.
Make sure the cylinders move at the same time through the cycle.
10. Hold the hydraulic lever with the cylinders fully extended.
11. If the cylinders are not operating together, cycle the cylinders to remove the remaining air.
IMPORTANT: *Do not loosen any hydraulic fittings to bleed air from the system.*
12. Stop the engine, apply the park brake, and take the key with you.
13. Check the tractor hydraulic oil reservoir to make sure the hydraulic oil is still within operating limits.
14. Make sure all lift cylinders are operating together before starting any field operation.
15. Fully raise the machine when making turns during field operation.
This will make sure that the cylinders are operating together and keep the machine level during operation.

3.7.3 Bleed the air from the hydraulic fold system

Before starting the procedure

WARNING:

Leaking fluid under pressure can enter the skin causing serious injury. Release pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Wear correct hand and correct eye protection when looking for leaks. Use a piece of cardboard or paper instead of your hand. Any fluid injected into the skin can cause gangrene. The fluid must be removed by a doctor familiar with this type of injury.

**WARNING:**

Be careful of sweeps or blades when folded to prevent serious injury. Never keep the machine with the wings in the folded position.

IMPORTANT: *Do not fold or unfold the fold system before bleeding air from the fold system.*

To bleed the air from the hydraulic fold system, connect the machine to a tractor that is the correct size to operate the machine. See the information for minimum tow vehicle weight.

Completely bleed the hydraulic system of air when:

The fold system is filled with hydraulic oil for the first time.

Air has entered the hydraulic system through a leak or through repair of the hydraulic system.

Procedure

1. Set the tractor hydraulic flow to less than 20 gal/min (75.7 L/min).
IMPORTANT: *If the hydraulic flow is set to more than 20 gal/min (75.7 L/min), the hydraulics will not operate correctly.*
NOTE: *Restrictors are installed in the fold cylinders to prevent falling of the wings. Never remove the restrictors, or the machine will not fold correctly.*
2. Stop the engine, apply the park brake, and take the key with you.
3. Connect the fold system hoses to the tractor.
4. Make sure the tractor reservoir is full of the hydraulic oil required by the manufacturer. **IMPORTANT:** *Do not loosen any hydraulic fittings to bleed air from the system.*
5. Remove the pins from the rod ends of the fold cylinders.
6. Make sure the rod ends of the fold cylinders will not come into contact with any obstructions. If a blockage is present, lift the rod ends of the fold cylinders.
7. Use the remote lever in the tractor to fully extend and retract the fold cylinders. Extend and retract multiple times.
8. If the fold cylinders are not operating together, cycle the fold cylinders to remove the remaining air.
IMPORTANT: *Do not loosen any hydraulic fittings to bleed air from the system.*
9. Stop the engine, apply the park brake, and take the key with you.
10. Check the tractor hydraulic oil reservoir to make sure the hydraulic oil reservoir is still within operating limits.
11. Connect the rod ends of the fold cylinders to the machine.
12. Find an area large enough for the machine when unfolded.
13. Park the machine on a solid, level surface. Stop the engine, apply the park brake, and take the key with you.
14. With the tractor at a low idle, slowly engage the hydraulics to fold and unfold the machine.
15. Fully extend the fold cylinders to let the wings flex freely.

3.8 Frame height cylinder phasing

When the support cylinders extend to the same length at the same time the support cylinders are in phase. If the cylinders do not extend to the same length at the same time then the cylinders must be put in phase.

Frame height cylinders that are out of phase will cause the machine to not be level with the ground when lifting or lowering the machine. A frame that is not level to the ground will cause different seed depth between each toolbar.

3.8.1 Put the frame height cylinders in phase

Before starting the procedure

To put the frame height cylinders in phase the machine must be connected to the correct size of tractor to operate the machine.

Put the frame height cylinders in phase to make sure the cylinders are moving to the same length at the same time.

Procedure

1. Lift the frame of the machine to the highest position.
2. Hold the hydraulic lever in the raised position for five seconds.

After finishing the procedure

Make sure the frame height cylinders are phased by lowering the machine to the ground and raising the machine to half of the fully raised height. If the frame is level to the ground then the cylinders are in phase.

3.9 Blower

The blower system for the machine generates air pressure/flow to carry the seed or other input products through the system to the implement. A hydraulic motor drives the blower system. Two 3/4 inch hydraulic lines supply oil to the blower.

The only part on the blower that can be serviced is the shaft seal. The shaft seal can be replaced if the motor leaks at the shaft. Do not disassemble the motor to replace the shaft seal. The shaft seal is fastened by a snap ring and can be removed with a seal pick.

IMPORTANT:

Be sure that the case drain line on the blower motor is not connected to pressure. Damage to the shaft seal or motor will result.

IMPORTANT:

Do not under any circumstances disassemble the motor. The motor is very difficult to correctly assemble and motor destruction will result. If a motor failure occurs, get a replacement motor from the dealer.

3.9.1 Blower speed

Operate the blower at as slow a speed as possible to prevent damage to seed. If operated too slowly, line blockage will occur. Typical blower speeds are between 3000 and 6000 rpm. The drill width, product, rate, humidity, and other factors can change blower speed.

If a run blockage monitor is not used, make sure all runs are operating after changing blower speeds. To check the runs:

1. Turn the meter(s) with the blower running
2. Make sure there is product at each ground opener



The number of outlets on the implement will directly change the blower rpm. The more outlets in use, the higher the pressure required to keep blower rpm. See your dealer for hydraulic adjustments to your tractor, if necessary.

One method to determine blower RPM is to remove a final run from the seed boot or shoe. Hold the hose about 5 ft. (1.5 meter) off of the ground pointing straight up. Turn product out of the meter with the blower running. The product coming from the hose must blow out of the hose approximately 8 inches (203 mm) into the air. Adjust blower RPM as required.

3.10 Meters

3.10.1 Change the metering wheels

Procedure

1. Lower the plenum (1) and turn the tractor off.
 2. Turn the welded hex nuts (2) to close the hopper gates (3) for the front and rear tanks.
 3. Release the clean out tray latches (4).
 4. Use the clean out tray handle (5) to open the clean out tray and remove any product.
 5. Lower the meters by the two large over center latches (6) on each side of the meter.
- 
- Fig. 18
6. Pull the hairpins (1) to remove the motors (2).
- NOTE:** The key may fall out when the motors are removed.
7. Remove the four 1/4 inch bolts (3) on the flange bearings (4).
 8. Pull the shaft assembly straight out of the meter.
 9. Remove the 5/8 inch lock collars (5) on one side.
 10. Move the spacers (6) and metering wheels (7) off of the shaft.
- 
- Fig. 19
11. Assemble the meter in the opposite order with the necessary metering wheels.

3.10.2 Meter latches

The meter latches can be adjusted to let the meter close tight against the hopper shut off assembly where product does not leak out.

With the meter correctly adjusted, there should be no gap seen between the meter and the shut off assembly.

To adjust the meter to hopper shut off:

1. Loosen the jam nuts (1) and the two 3/8 inch carriage bolts (2) on the over center latches.
2. Extend or retract the carriage bolts until there is correct preload on the clamp. If the preload is too small the meter will not seal correctly. If too tight the clamp will not close.
3. If necessary, loosen the two 3/8 inch bolts (3) on the rear hinge of the meter. This will let the meter lift or lower at the hinge.




Fig. 20

3.10.3 Cleanout tray latches

The clean out tray latches (1) can be adjusted to increase or decrease the preload on the meter door. If the preload is too small, the tray will not seal correctly. If the tension is too tight, the latches will not easily close.

To adjust the clean out latches:

1. Unlock the clean out latch.
2. Turn the two stop-nuts (2) evenly in or out.
3. Lock the latch and make sure the preload is correct before operation.




Fig. 21

3.10.4 Meter shaft adjustment

For larger products such as beans and peas, the meter shaft (1) must be lifted to let the products pass. The bearings (2) have slots for adjustment.

To lift the meter shaft:

1. Remove the hair pin (3) and remove the motor (4).
- NOTE:** *The key may fall out when the motors are removed.*
2. Loosen the four 1/4 inch bolts (5) that hold the bearings to the meter.
 3. Move the assembly up or down as necessary.
 4. Make sure each end of the shaft assembly is at approximately the same height for the most accurate metering.
 5. Tighten the four 1/4 inch bolts that hold the bearings to the meter.




Fig. 22

3.11 Plenum operation

The plenum supplies the air from the blower to all the venturi cups. Make sure that the plenum is fully lifted and sealed against the seed hose bulkhead and fans before operation, transport and storage.

3.11.1 Lower the plenum for service and calibration

The plenum must be lowered for calibration and service. This is done with an electric switch. Procedure

1. Use the electric rocker switch (1) to raise and lower the plenum for service.
2. Push the switch down to lower the plenum.
3. Push the switch up to lift the plenum.




Fig. 23

3.11.2 Clean out the plenum

During operation, product can enter the plenum at the venturi. If this product collects in the plenum it can cause blockage and the plenum must be cleaned out.

Procedure

1. Remove the four hex bolts (1) that attach each of the two access panels (2).
2. Remove the two access panels .
3. Clean out the collected product.
4. Install the two access panels and attach each panel with four hex bolts.




Fig. 24

3.12 Wireless blockage monitor

The wireless blockage monitor system uses inline sensors on each seed run to sense blockage or plugs. The ECU connects wirelessly with an iPad in the cab. An iPad is required with this machine and is not included with this machine.

The app must be downloaded onto the iPad, which can be found on the iPad App Store. Search the app store for "wireless blockage monitor". Download the Recon App. Follow the instructions for setting up the blockage configuration. From this app, the user can see the newest blockage monitor manual. It can also be found online at www.intelligentag.com/support/.

3.13 Prepare the machine for transport

Before starting the procedure

Stop the tractor before preparing the machine for transport. Remove the remaining seed from the hopper before transporting.

Procedure

1. Use the tractor hydraulics to lift the frame of the machine to the highest position.
2. Use the tractor hydraulics to fully lift the toolbars of the machine.
3. Use the tractor hydraulics to fully lift the wings of the machine.
4. Stop the engine, apply the tractor park brake, and take the ignition key with you.
5. Move the handle of the toolbar lock-out (1) to the closed position.




Fig. 25

6. Lock the wings in the raised position by installing the wing lock pins (1) and wire lock pins (2) in the wing lock brackets (3).




Fig. 26

3. Operation

7. Lock the toolbars in the raised position by moving the toolbar locks (1) to the locked position (2).
8. Install the transport locks and lower the frame onto the locks.
9. Make sure the rear facing lamps and reflectors are free of dust and operate correctly.




Fig. 27

3.14 Prepare the machine for seeding

Before starting the procedure

The machine must be connected to a tractor that is the correct size to operate the machine. See the information for the minimum tow vehicle weight.

Make sure there is enough area around the machine to completely lower the wings.

Procedure

1. Stop the tractor. Stop the engine, apply the tractor park brake, and take the ignition key with you.
2. Make sure the area below the machine is clear of people, pets, and obstructions.
3. Move the toolbar lock-out handle (1) to the open position.
4. Start the tractor.
5. Use the tractor hydraulics to remove any load from the toolbar locks by fully lift the toolbars.
6. Use the tractor hydraulics to remove any load from the wing lock pins by fully lift the wings.
7. Stop the engine and take the ignition key with you.
8. Remove the wing lock pins (1) and wire lock pins (2) from the wing lock brackets (3). Install the wing lock pins in the storage brackets on the frame.
9. Start the tractor.
10. Use the tractor hydraulics to lower the wings to the operating position.
11. Move all the toolbar locks (1) to the unlocked position (2).
12. Use the tractor hydraulics to lower the toolbars and move the hydraulic lever to full down position.
13. Use the terminal to set the initial down pressure.
14. Stop the engine and take the ignition key with you.




Fig. 28




Fig. 29




Fig. 30

3. Operation

15. Install the initial sequence of seed depth collars (1) on the shafts of the frame height cylinders (2).
16. Check the seed depth and the down pressure of the machine. Make the needed adjustments.




Fig. 31

3.15 Level the wings to the center frame

Use this procedure to level the wings to the center frame.

Before starting the procedure



WARNING: Avoidance hazard. Clearance.

Serious personal injury can occur.

Make sure all persons are clear of the area before operating the

machine. The machine must be connected to a tractor that is the correct size for operation. See the specifications section for more information.

Make sure there is area around the machine to fully lower the wings.

Procedure

1. Park the drill on a flat and level surface.
2. Stop the engine, apply the park brake, and take the key with you.
3. Lift the drill to the highest position and then hold the hydraulic lever in the raised position for five seconds.




Fig. 32

4. Install the cylinder stop collars (1) on the lift cylinders to approximate operating height.
5. Make sure all four lift cylinders have the same stop collars installed.
6. Lower the drill frame until the weight of the machine is held by the cylinder stop collars.
7. Measure the distance (A) from the ground to the bottom of the frame (2). Measure in front of each of the frame and the wing support cylinders (3).

3. Operation

8. Adjust the adjusting rods (5) above each of the wing support cylinders (3). Adjust the adjusting rod until the measurement between the frame and the ground is the same. Adjust the adjusting rods by tightening or loosening the jam nut (4) on either end of the adjusting rod.
9. Make sure the measurement at each of the wing support cylinders is equal. Tighten the jam nuts against the tube that holds the adjustment rod.

3.16 Single-disc opener

3.16.1 Adjust the cast boot

If the cast boot goes out of adjustment, follow these steps to

adjust. **Procedure**

1. Loosen the two 1/2 inch hex bolts (1) that hold the pivot pin.
2. Push on the top of the boot until the front edge of the boot evenly rides on the disc .
3. Tighten the two 1/2 inch hex bolts.




Fig. 33

3.16.2 Opening disc scraper adjustment

The opening disc scraper (1) is adjusted correctly when the full length of the front edge (2) of the disc scraper lightly touches the opening disc (3). Adjust the opening disc scraper with the two nuts (4) fastening the disc scraper to the opener assembly.

NOTE: *The opening disc scraper and opening discs are painted from the factory. The paint must wear off before the disc scraper and disc will operate correctly.*

Adjust the opening disc scrapers according to field conditions and the wear of the disc scraper.




Fig. 34

3.16.2.1 Adjusting the opening disc scraper

Procedure

1. Loosen the jam nuts (1) on the top and bottom adjusting nuts.
2. Tighten the bottom adjusting nut (2) until the full length of the front edge (3) of the opening disc scraper lightly touches the opening disc (4). Keep the position of the opening disc scraper in the middle of the groove in the top adjusting nut (5). Keep the position by tightening or loosening the top adjusting nut.
3. Tighten the top adjusting nut until the bottom (6) of the opening disc scraper lifts off of the opening disc.




Fig. 35

3. Operation

4. Loosen the top adjusting nut until the bottom of the front edge of the opening disc scraper lightly touches the opening disc.
5. Tighten the jam nuts on the top and bottom adjusting nuts.

After finishing the procedure

Adjust the opening disc scrapers on the remaining opening disc assemblies.

3.16.3 Fertilizer bander attachment

The optional fertilizer bander attachment (1) applies anhydrous ammonia or fertilizer between the two furrows that are made by the opening disc assemblies. The fertilizer bander attachment is installed forward of the opening disc assemblies.




Fig. 36

The depth at which the fertilizer bander applies the fertilizer is set using a cam block (1). The slots (2) in the cam block determine the depth of the fertilizer. The deeper the slot in the cam block; the deeper the fertilizer is applied.

IMPORTANT: *When operating in rocky soil conditions, do not operate at a high rate of speed. High speeds in rocky conditions will damage the fertilizer bander attachment.*




Fig. 37

3.16.3.1 Adjusting fertilizer bander depth

Before starting the procedure

To adjust the fertilizer bander depth the machine must be connected to the correct size of tractor to operate the machine.

Procedure

1. Raise the frame of the machine until the bander discs are off of the ground.
2. Stop the tractor. Stop the engine, apply the tractor park brake, and take the ignition key with you.

3. Place a wooden block below one of the discs (1) on the fertilizer bander attachment that is to be adjusted.
4. Start the tractor and lower the machine to the ground.
5. Stop the tractor. Stop the engine, apply the tractor park brake, and take the ignition key with you.




Fig. 38

6. CAUTION:



Make sure the fertilizer bander disc is firmly supported by the wooden block. If the fertilizer bander disc is not firmly supported then start the tractor, raise the machine, and reposition the wooden block.

Remove the bolt (1) and washer (2) securing one end of the cam block (3) for the bander disc (4) being supported by the wooden block.




Fig. 39

7. Slide the cam block out of the bander frame.
8. Install the cam block in the bander frame so the desired depth groove in the cam block will contact the bander disc strut.
9. Secure the cam block in the bander frame using the existing bolt and washer.
10. Start the tractor and raise the machine until the bander disc is off of the wooden block.
11. Stop the tractor. Stop the engine, apply the tractor park brake, and take the ignition key with you.
12. Remove the wooden block from below the bander discs.

After finishing the procedure

Use the same procedure to adjust the remaining bander disc on the fertilizer bander attachment and the other bander attachments.

3.16.4 Opening disc offset

The opening disc offset is the amount of offset (A) between the two opening discs (1) on each toolbar. The opening disc offset prevents material from accumulating between the two opening discs on the opening disc assembly.

The opening disc offset is set at 114 mm (4.5 inch) at the factory, but can be adjusted from 38 mm to 165 mm (1.5 to 6.5 inch).

Increase the opening disc offset for wet, sticky soils.

Decrease the opening disc offset for dry, sandy soils.

If operating in soil with large rocks, set the opening disc offset to the maximum offset.

If the opening disc offset is too wide, there will not be enough soil movement for sufficient trench closure.

If the opening disc offset is too narrow, material will build between the two opening discs.

Use the five sets of holes on one side (1) of the opener mount to adjust one of the opening discs. Use the two sets of holes on the opposite side (2) to adjust the other opening disc offset. Each set of holes will change the offset by 25 mm (1 inch)(A).




Fig. 40




Fig. 41

Opening disc offset table

The following table shows the opening disc offset according to the position of the opening disc struts (1) on the opening disc mount (2). The first column shows the number of pairs of holes (3) forward of the opening disc strut on the five position side of the opener mount. The second column shows the position of the opening disc strut on the two position side of the opener mount, forward or rear. The third column shows the opening disc offset.




Fig. 42

Number of Pairs of Holes Forward of the Opening Disc Strut	Position of the Opening Disc Strut	Opening Disc Offset
0	Rear	6.5 inch (165.1 mm)
0	Forward	5.5 inch (139.7 mm)
1	Forward	4.5 inch (114.3 mm)
2	Forward	3.5 inch (88.9 mm)
3	Forward	2.5 inch (63.5 mm)
4	Forward	1.5 inch (38.1 mm)

3.16.4.1 Setting opening disc offset

The opening disc offset is adjusted according to field conditions.

Procedure

1. Lift the frame of the implement to the highest position.
2. Stop the tractor. Stop the engine, apply the tractor park brake, and take the ignition key with you.
3. Support the opening disc strut (1) and opening disc (2).
4. Remove and keep the four bolts, washers, and lock nuts attaching the opening disc strut to the opener mount (3).
5. Move the opening disc strut to the new position of the opener mount.
6. Attach the opening disc strut to the opener mount with the existing bolts, washers, and lock nuts.




Fig. 43

After finishing the procedure

Move the remaining opening disc struts to the new position on the opener mounts on the remaining opening disc assemblies.

3.16.5 Packing tires

The packing tires (1) located behind the opening disc assemblies (2) close the two furrows made by each of the opening discs.

The packing tires operate at an angle to the travel of the drill. The angle closes the two furrows and removes any accumulated mud from the tires when operating in wet soil conditions. The packing tires on the right-hand side of the drill are angled toward the center of the drill. The packing tires on the left-hand side of the drill are angled toward the center.




Fig. 44

3.16.6 Seed depth

Seed depth is how deep the drill plants the seed in the ground. The seed depth changes in relationship to how close the frame of the drill is to the ground. The closer the frame is to the ground; the deeper the drill plants the seed.




Fig. 45

Adjust the seed depth by installing seed depth collars (1) on the shafts of the frame height cylinders (2). Install the same sequence of depth collars on each frame height cylinder.

There are four different widths of depth collars. The color of the depth collar identifies the width of the depth collar. The following is the color and width of each depth collar.

- Blue = 3.0 inch (7.62 cm)
- Silver = 1.5 inch (3.81 cm)
- Green = 0.75 inch (1.91 cm)
- Red = 0.50 inch (1.27 cm)

Different sequences of depth collars will cause different seed depths. Use the best sequence of depth collars for the field conditions.




Fig. 46

3.16.6.1 Check the seed depth

Check the seed depth in the field before seeding with the machine.

Procedure

1. Connect the machine to a tractor of the correct size to operate the machine.
2. Set the seed depth of the machine by installing the initial sequence of the seed depth collars.
3. Fill the seed hopper or seed container with seed.
4. Put all the components of the machine in the field position.
5. Lower the machine and plant a straight section at the needed speed for approximately 55 m (30 yd).
6. Stop the tractor. Stop the engine, apply the tractor park brake, and take the ignition key with you. Find one of the furrows behind the machine.

7. Carefully remove the soil covering four of the planted seeds.



Fig. 47

8. Measure the distance from the surface of the soil to the bottom of each seed. Use one of the following two methods.

- **Using a ruler and a straight edge:** Place the straight edge flat against the surface of the ground. Hold a ruler vertically in the seed furrow next to the seed. Measure the distance from the bottom of the seed to the bottom of the straight edge.

- **Using the seed finding tool:** Place the long flat section (1) of the seed finding tool against the ground with the short flat section (2) inside the seed furrow (3).

Press the short flat section in the ground until the long flat section is flush with the ground. Measure the depth of the furrow using the marks on the short flat section.




Fig. 48

Result

The measurement taken is the actual seed depth.

9. Check the depth of the seeds in two of the other furrows behind the machine.
10. Compare the measurements to the correct seed depth and adjust the machine as necessary.

After finishing the procedure

Continue to check the seed depth until the machine plants the seed at the correct seed depth.

3.16.6.2 Seed depth collar sequences

Each letter in the following chart represents the color of the depth collar.

- B = Blue
- S = Silver
- G = Green
- R = Red

The two rows of numbers below the letters in the chart are the total length of the depth collars in inches and centimeters.

3. Operation

B	B	B	B	B	B	B	B	B	B	B	B	B	S	S	S	S	S	
S	S	S	S	S	S	S	S	S	S	S	S	S	G	G	G	G	G	
G	G	G	G	G	G	G	G	G	G	R	G	R	G	G	G	G	G	
G	G	G	G	G	G	G	R	G	R	R			G	R	G	R	G	
G	G	R	G	R	G	R	R						R	R	R	R		
R	R	R	R	R									R	R				
R	R	R																
R																		
8.25	7.75	7.5	7.25	7	6.75	6.5	6.25	6	5.75	5.5	5.25	5	4.75	4.5	4.25	4	3.75	inch
21	19.7	19.1	18.4	17.8	17.1	16.5	15.9	15.2	14.6	14	13.3	12.7	12.1	11.4	10.8	10.2	9.5	cm

S	S	S	S	S	S	S	G	R	G	R	G	R		
G	G	G	G	R	G	R	R	R	R	R				
G	R	G	R	R			R	R						
R	R													
3.5	3.25	3	2.75	2.5	2.25	2	1.75	1.5	1.25	1	0.75	0.5	inch	
8.9	8.3	7.6	7	6.4	5.7	5.1	4.4	3.8	3.2	2.5	1.9	1.3	cm	

SECHE0110064501

Fig. 49

3.16.6.3 Initial seed depth collar sequences

The initial seed depth collar sequence is the total length of the depth collars installed on the shaft of the frame height cylinders. The initial seed depth collar sequence is a starting point. The sequence of depth collars will change with the field conditions.

Use the following initial seed depth collar sequences when checking seed depth.

- Small Grains and Beans: 7.5 inch (19.1 cm) sequence (blue (2), silver (1))
- Canola: 9.75 inch (24.8 cm) sequence (blue (2), silver (2), green (1))

3.16.6.4 Adjust the seed depth

Procedure

1. Raise the drill frame to the highest height.
2. Install the recommended initial sequence of depth collars (1) on the shaft of each of the frame height cylinders (2).
NOTE: See the decal on the front of the frame for the sequence of seed depth collars.
3. Operate the drill in the field and check the seed depth.
4. Adjust the sequence of seed depth collars. Check the seed depth until the seed is at the correct seed depth.




Fig. 50

SECHE0110085002

3.17 Double-disc opener

3.17.1 Seed depth adjustment

The seed depth of each opener is controlled by the position of the depth cam assembly on the back of the opener frame. To change the seed depth, pull the spring loaded D-handle out of the notch, rotate the cam to a different position, and release the D-handle. To decrease the seed depth, rotate the cam to a notch more forward.

NOTE: To adjust the down pressure does not change the seed depth. The seed depth is controlled by the adjustment on the press wheel.




Fig. 51

3.17.2 Opener down pressure

The opener down pressure is adjusted by changing the notch setting on the top parallel link (1). The first notch, (2), provides the least down pressure. The rear notch, (5), provides the greatest down pressure.

NOTE: To adjust the opener down pressure does not change the seeding depth. The seed depth is controlled by the adjustment on the press wheel.




Fig. 52

3.17.2.1 Adjust the opener down pressure

To adjust the opener down pressure does not change the seeding depth. The seed depth is controlled by the adjustment on the press wheel. Initially set all of the openers in the same notch.

Procedure

1. Raise the drill until the openers are off the ground.
2. Stop the tractor, stop the engine, apply the park brake, and take the ignition key with you.
3. Move the adjustment bolt from one notch to the other by grasping each end of the bolt and moving it to the new notch setting.
4. Lower the drill until the .75 to 1 inch (2 to 2 1/2 cm) measurement (A) is reached on all openers.




Fig. 53

3. Operation

Result

If the measurement (A) is less than 2 to 2 1/2 cm (.75 to 1 in) increase down pressure in the monitor.
If the measurement (A) is more than 2 to 2 1/2 cm (.75 to 1 in) decrease down pressure in the monitor.

5. Measure the frame height cylinders from the cylinder head casting to the clevis on the rod end of the cylinder.
6. Determine how many stroke control segments are needed to hold the drill at this height.
7. Place the same number of stroke control segments on each of the frame height cylinders.
8. Place the openers in the tire track in a higher setting if more down pressure is required.

3.17.3 Soil firming device adjustment

The purpose of the soil firming device (1) is to prevent blowout and to minimize soil and residue disturbance. For most seeding conditions, the firming device angle should be set at approximately 28.6 cm (11.25 in) measurement (A). If you are seeding excessively deep or shallow, you may need to change the angle of the firming device to match your conditions.




Fig. 54

3.17.4 Rigid scraper adjustment

The rigid scrapers should maintain slight contact with the inside of the blades for best performance. If adjustment is required, loosen the two mounting bolts and adjust the scraper. Tighten the mounting bolts.

3.17.5 Opener blade pinch point

The point at which the two opener blades contact each other is called the pinch point. The pinch point must be properly setup with the right amount of pressure to maximize performance and extend blade and bearing life. If the pressure is too tight, excessive wear, bearing failure and plugging may occur. If the pressure is too light, bearing failure and seed trench deterioration may result.

3.17.5.1 Check for a loose pinch point

Procedure

1. Raise the drill until the openers are off the ground.
2. Stop the tractor, stop the engine, apply the park brake, and take the ignition key with you.
3. Grasp a blade from behind and rotate it in the forward direction.

Result

The pinch point pressure should be adequate enough to rotate both blades while turning only one. A slight loss of contact during rotation is acceptable but ideally you want full contact between the blades during rotation.

4. If the blades are loose, remove shims from behind the opener blades to move them closer together.
5. Remove the number of shims necessary to maintain the pinch point.

6. Store the shims on the other side of the bearing under the dust cap.

3.17.5.2 Check for a tight pinch point

Procedure

1. Raise the drill until the openers are off the ground.
2. Stop the tractor, stop the engine, apply the park brake, and take the ignition key with you.
3. Grasp each blade from behind and rotate them independently in the opposite direction of each other.

Result

The blades should glide against each other easily without binding.

4. If the blades bind or work against each other while rotating, install shims between the opener bar and the blade to space them apart.
Shims are sometimes required when new blades are installed.
5. Add the number of shims necessary to maintain the pinch point.

3.17.5.3 Add or remove opener shims

Each opener shim is equal to .8 mm (1/32 in)

Procedure:

Loosen the 3/4 inch bolt (1) (the left side has left hand threads) that mounts the blade to the opener bar.

2. If equipped with soil control devices, remove the locking arm 3/8 inch bolt (2) and the locking arm (3) first.
3. Slowly remove the blade (4) and bolt (1) together being careful not to drop and lose any shims (5).
4. Remove the 3/4 inch bolt (1) and transfer the shims (5) from one side to the other, depending on the adjustment required.




Fig. 55

5. Insert the 3/4 inch bolt (1) through the blade bearing and place the shims (5) on the end of the bolt, against the bearing.
6. Reattach the blades (4) to the opener bar with the 3/4 inch bolt (1).
7. Tighten the bolts and recheck the pinch point pressure.
8. Install the soil control devices, if equipped, and set the angle while tightening the 3/4 inch bolt (1).
9. Check the pinch point pressure.
10. If the pinch point pressure is correct, attach the locking arm (3) and the locking arm 3/8 inch bolt (2).

3.18 Toolbar down pressure

A hydraulic cylinder (1) applies toolbar down pressure on each toolbar (2). The cylinders apply a constant down pressure through the full range of movement of the toolbar. An active hydraulic circuit maintains uniform pressure to each hydraulic cylinder.

Use the terminal to set the toolbar down pressure. The toolbar down pressure can be adjusted from 1034 kPa to 17237 kPa (150 psi to 2500 psi). Set the toolbar down pressure high enough for correct disc penetration and correct soil compaction. The toolbar down pressure adjustment will change with field conditions, seed depth, soil type, and ground speed.

Operate the tractor hydraulic remote that the toolbar down pressure is connected to at full output or fully open. Operating the hydraulic remote at full output reduces the back pressure on the toolbar down pressure return lines.




Fig. 56

3.19 Turn the machine at the edge of a field

When turning at the edge of a field, or headland, complete the following steps.

Procedure

1. When approaching the turn, slow the tractor and machine to an acceptable rate of speed to complete the turn.
2. Begin to raise the frame of the machine and start the turn at a point where the machine will clear any obstacles to the outside of the turn.
IMPORTANT: *When lifting the machine for a turn, only lift the frame with the frame height cylinders.*
3. Complete the turn. Watch and make sure the edge of the machine clears any obstacles.
4. After completing the turn, align the machine with the last pass, permitting for the correct amount of spacing or overlap.
5. Lower the frame of the machine to start the next pass.
6. Increase the speed of the tractor and machine to the operating speed.

3.20 Software information

3.20.1 Software icon descriptions

Main screen icons

-  Master apply switch
-  Switch between preset down pressure values
-  Virtual switch box
-  Down pressure settings
-  Product rate settings
-  Next page
-  Calibration screen
-  Totals screen
-  Settings screen
-  Maintenance screen
-  Go back to previous screen

Virtual switch box

-  Select to turn the section on or off Select
-  to prime the meters

Down pressure

-  Increase down pressure
-  Decrease down pressure
-  Select to see the preset value information

Product rate

-  Increase product application rate
-  Decrease product application rate

Maintenance

-  Select to view active errors
-  Select to view stored errors

3.20.2 Main work screen

The implement's operation and monitoring are done from the main work screen.

The main work screen contains this information:

- (1) Active errors
- (2) Section status
- (3) System status
- (4) Product level information
- (5) Product rate information




Fig. 57

Active errors

Active error icons include:

-  Rate error
-  Meter error
-  Case drain error
-  Fan speed error
-  Down pressure error
-  Service interval warning Product
-  low - Yellow background Product
-  bridged
-  Product empty - Red

Section status background

There are three sections for the implement. The color will change with the status of each section:

- Green - On

3. Operation

- White - Off when controlled by the virtual switch box or Task Controller
- Yellow - Standby

System status

The speedometer (1) will show the speed of the source of the ground speed:

-  Drill GPS
-  Tractor ISOBUS GPS
-  Hold speed

Select the fan control (2) to turn on or off. The background of the fan control will change:

- Green - manual on
- White - manual off
- Yellow - manual on, rate not met

NOTE: *If the state is yellow, the target is not met and seeding performance will be compromised.*

Below the fan control is a bar chart (3) that shows the target speed and the actual speed.

Select the down pressure (4) to turn on or off. The background of the down pressure will change:

- Green - manual on
- White - manual off
- Yellow - manual on, rate not met

NOTE: *If the state is yellow, the target is not met and seeding performance will be compromised.*

Below the down pressure is a bar chart (5) that shows the target pressure and actual pressure.

The lift state (6) will change:

-  Up
-  Down

Area counter (7) also shows on the main screen.




Fig. 58

Product level information

The product level for each hopper (1) is shown.

Select **Reload** to see the reload screen.




Fig. 59

Product rate information

The product rate information includes the target rate and actual rate for each product. Select the target rate box to change the value.

3.21 System information

3.21.1 Terminal information

Read and understand the terminal operator manual(s) before reading the implement software information.

The terminal operator manual can contain this information:

- Installing the terminal in the tractor
- Button or touch screen operation
- Changing data information
- Volume control
- Display brightness
- Terminal and implement language and measurement units
- Setting the date and time
- Auxiliary input setup for the external master switch
- Ground speed calibration
- Making as applied maps, if available
- Variable rate application, if available

NOTE: For more information on section control with a C1000 terminal, see the Task Controller operator manual.

For more information on section control with a C3000 terminal, see the Auto-Guide 3000 Advanced for C3000 terminal operator manual.

3.21.2 Implement software identification

The software identification information is located on the software maintenance screen.

Select the icons in this order:



The information (1) will change when software is updated.

Give this information to your dealer when necessary:

Software version:	
Software build:	

Select  to go back to the settings screen.




Fig. 60

3.21.3 Master switch

There are two types of master switches:

- External master switch
- Terminal master switch

See the information for external master switch or terminal master switch.

The master switch must be turned off when:

- Transporting
- Stationary
- The operator is not in the tractor

3.21.3.1 External master switch

An external master switch can be used if:

- The terminal harness has an auxiliary function connection, or
- The terminal or tractor has an external auxiliary function switch

Connect the external master switch to the terminal harness close to the terminal. Mount the external master switch within reach of the operator.

During field operation, move the external master switch to the on position to start planting. Ground speed will control the product application rate.

Move the external master switch to the off position to stop planting. The external master switch must be in the off position when:

- Not planting
- Transporting
- Doing maintenance

3.21.3.2 Terminal master switch

During field operation, select  to start planting.

The background color of the terminal master switch will change:

- White - terminal master switch off
- Yellow - stand-by
- Green - seeding

Ground speed will control the product application rate.

Select  to stop seed flow.

3.21.4 Virtual switch box

On the implement main screen, select  to see the virtual switch box.

The virtual switch box is used to manually turn individual sections or hoppers on and off without turning the master switch off.

The virtual switch box is also an alternative to a physical switch box, if one is not available.

There are two ways turn on or off a section:

- Select the icon (1) on the right side of the screen, or
- Select the section (2)

Select the correct hopper (3) to turn on or off.

If  is selected, the meters assigned to the product and/or sections that are active (on the virtual switch box screen) will turn one complete




Fig. 61

3. Operation

revolution at the set rpm "meter speed" on the calibration screen.

This procedure lets the operator run a some product out of the meter to be sure no lines are plugged before starting a field.

Select  to go back to the settings screen.

3.22 Implement setup

3.22.1 Change the implement settings

Procedure

1. Select the icons in this order:



2. If a lift switch is connected, enable the lift switch (1).
3. If the lift switch is reversed, make sure there is a checkmark in the box (2) next to **Reversed**.
4. Select the box (3) next to **Low Speed Alarm** to set the low fan speed alarm.
5. To hear a sound each time the master apply switch is turned on, enable the master apply beep (4).
6. Select the ground speed source (5).
 - Drill GPS
 - ISOBUS
7. Select the type of rate control (6).
 - Per section
 - Full width of the implement
8. The section measurements (7) are determined by the openers on the machine.
9. With the req fan A (8) selected the minimum fan speed must be met or the machine will not apply.
10. Select  to go back to the main screen.




Fig. 62

3.22.2 Calibrate a drill section

NOTE: The catch bag must be empty each time the calibration process is started.

Procedure

1. Weigh the empty container.
2. Put the container in position to catch the product from one section.
3. On the terminal, select the icons in this order:



3. Operation

4. Put a checkmark in the box (1) for the section to be calibrated.
5. Use the keypad outside the machine to start and stop the motors. The #1 button controls the front hopper and the #2 button controls the rear hopper.
6. Weigh container for each product. Use the scale supplied to weigh the container.
7. Calculate the catch weight. Subtract the container weight from the total to get the catch weight.
8. Enter the catch weight value (2) for each product.




Fig. 63

9. Select to go back to the main screen.

3.22.3 Set the down pressure

Procedure

1. Select the box (1) below to enter a specific value.
2. Use the number pad to enter the down pressure value.
3. Select .
4. Select to move between two preset down pressure values.
5. To change the preset values or the other values all on one screen, on the select right side of the screen.




Fig. 64

6. Select the box (1) next to  to enter a specific value.
7. Use the number pad to enter the down pressure value.
8. Select .
9. Select the box (2) next to **Bump Amount** to change the interval the down pressure will change.
10. Use the number pad to enter the down pressure value.
11. Select .
12. To increase the down pressure by the bump amount, select .
13. To decrease the down pressure by the bump amount, select .
14. To change one of the preset down pressure values, select the box (3) next to .
15. Use the number pad to enter the down pressure value.
16. Select .
17. Select  to go back to the main screen.




Fig. 65

3.22.4 Set the product rate

Procedure

1. To change **Rate 1** (1), select the box (2) next to  to enter a specific value.
2. Use the number pad to enter the down pressure value.
3. Select .
4. To change **Rate 2** (3), select the box (4) next to  to enter a specific value.
5. Use the number pad to enter the down pressure value.
6. Select .
7. To change more product rate information, select  on the right side on the screen.




Fig. 66

3. Operation

8. To change **Rate 1** (1), select the box (2) next to to enter a specific value.
9. Use the number pad to enter the down pressure value.
10. Select .
11. To change **Rate 2** (3), select the box (4) next to to enter a specific value.
12. Use the number pad to enter the down pressure value.
13. Select .
14. Select the one of the boxes (5) next to the **Bump Amount** to change the interval the product rate will change
15. To increase one of the product rates by the bump amount, select .
16. To decrease one of the product rates by the bump amount, select .
17. Select to go back to the main screen.




Fig. 67

3.22.5 Load the bins

Procedure

1. Select **Reload** (1).




Fig. 68

2. Select **Prod 1 100%** (1) to made hopper 1 (2) full.
3. Select **Prod 2 100%** (3) to made hopper 2 (4) full.
4. To add product by weight to the hoppers, select one of the boxes (5) next to **Weight**.
5. Use the number pad to enter the value.
6. Select .
7. Select the Density value box (6) for each product.
The product density must be added for each product to have an accurate value of % full and weight.
8. Use the number pad to enter the value.
9. Select .
10. Select to go back to the main screen.




Fig. 69

3.23 Totals

Select the icons in this order to see the totals screen:



The totals screen includes this information:

- (1) Two area counters that can be reset
- (2) Two hopper area counters that can be reset
- (3) Lifetime area counter
- (4) Lifetime metering counter
- (5) Lifetime product used counter
- (6) Lifetime fan usage counter

Select  to go back to the main screen.




Fig. 70

3.24 Maintenance

Select the icons in this order to see the maintenance screen:



Select  to see a list of active errors.

Select  to see a list of stored errors.

Select  to go back to the main screen.




Fig. 71

4 Maintenance

4.1 Lubrication points	107
4.1.1 Lubrication and maintenance chart.....	107
4.1.2 Lubrication fitting locations.....	108
4.2 Service the wheel bearings	112
4.3 Storage	113
4.3.1 Prepare the machine for storage	113
4.3.2 Prevent corrosion of extended hydraulic cylinders	114
4.3.3 Remove the machine from storage.....	114

4.1 Lubrication points

See the machine specification for the correct lubricant.

Shut off the engine, lower the machine to the ground, set the parking brake and take the key with you.

Do not let grease build up on or around parts, especially when operating in sandy soil.

Make sure to clean the lubrication fittings fully before connecting the grease gun.

Watch each lubrication point while lubricating to make sure the lubricant applies correctly.

Check for any loose, missing, or worn parts when lubricating the machine.

Check the lubrication service schedule for the correct lubrication interval.

4.1.1 Lubrication and maintenance chart

Severe conditions or conditions that are not normal will require more frequent lubrication.

See the machine specifications for the correct type and quantity of lubricant.

10 hours or daily	50 hours or weekly	1000 hours or yearly	
X			Lubricate the transport wheel walk beams, two fittings per beam.
X			Lubricate the transport wheel struts, two fittings per strut.
X			Lubricate the rear hitch pivot pins, one fitting per pivot.
X			Lubricate the bander disc struts on the fertilizer bander attachment, one fitting per strut.
	X		Lubricate the press wheel swivel, one fitting per opener.
	X		Lubricate the hopper shutoff bushings, two per shutoff
	X		Lubricate the wing frame pivot points, one fitting per pivot.
	X		Lubricate the ring hitch, two fittings per hitch.
	X		Inspect all hardware installed on the machine for the correct torque.
	X		Inspect all wheel lug bolts and wheel nuts for the correct torque.
	X		Check air pressure of all tires. Inflate tire to correct pressure.
	X		Clean any dirt or grease from moving parts.
		X	Lubricate the packing wheel and disc hub, one fitting per hub

4


4. Maintenance

10 hours or daily	50 hours or weekly	1000 hours or yearly	
		X	Remove and clean the bearings from each hub assembly. Fill the bearings and hubs with new grease.
		X	Remove and clean the bearings from each walking tandem. Fill the bearings with new grease.
		X	Inspect all hydraulic hoses and fittings for cracks or leaks. Replace any hoses or fittings as necessary.

4.1.2 Lubrication fitting locations

Transport wheel walk beams

Find the two grease fittings (1) on each transport wheel walk beam.




TLFBE0110456101

Fig. 1

Transport wheel struts

Find the two grease fittings (1) on each transport wheel strut.



TLFBE0110455801

Fig. 2

Rear hitch pivots

Find the one grease fittings (1) on each rear hitch pivot pin (2).




Fig. 3

Fertilizer bander strut pivot

Find the grease fittings (1) for each fertilizer bander strut pivot (2) in front of the pivot.




Fig. 4

Press wheel swivel

Find the grease fitting (1) for each press wheel swivel.




Fig. 5

4. Maintenance

Hopper shutoff bushings

Find the two grease fittings (1) on each shutoff.




Fig. 6

Wing frame hinge point

Find the one grease fitting (1) on each pivot point.




Fig. 7

Ring hitch

Find the two grease fittings (1) on each hitch.




Fig. 8

Packing wheel

Find the one grease fitting (1) on each wheel hub assembly.




Fig. 9

Disc hub

Find the one grease fitting (1) on each disc hub assembly.




Fig. 10

4.2 Service the wheel bearings

Clean and fill the wheel hubs yearly. Cleaning and filling the hubs removes all dirt and supplies fresh grease.

Procedure

1. Remove the hub and bearing.
2. Clean the old grease out.
3. Manually pack the bearings.
4. Assemble the hub and bearings.
5. With the hub cap off, use the grease fitting to fill the hub.
6. Stop filling the grease when it starts to push out the bearing.
7. Install the hub cap.

4.3 Storage

4.3.1 Prepare the machine for storage

Prepare the machine for storage at the end of each season. When possible, store the machine in a covered location with the wings lowered. Preventing rust will lengthen the life and assist in performance.

Procedure

1. Park the machine on a solid, level surface, away from other machines.
2. Use the tractor hydraulics to lower the wings of the machine.
3. Clean the machine of any dirt, grease, or other materials.
4. Put a protective layer of heavy oil or grease on all earth engaging parts to prevent rust.
5. Paint any damaged surfaces, surfaces with paint removed, or surfaces with rust.
6. Inspect the machine for any loose parts or hardware.
 - a) Replace any worn parts.
 - b) Tighten any loose hardware.
7. Lubricate all components of the machine.
8. Raise the machine and transport the machine to the area where the machine is to be kept. The area must be level and away from other machines.
9. Use the tractor hydraulics to lower the wings of the machine.
10. Stop the engine, apply the park brake, and take the key with you.
11. Remove the hardware that fastens the cylinder rod (1) of the wing lift cylinders to the wing frame. If equipped with folding wing extensions, remove the pins fastening the rod end of the wing lift cylinders to the wing extension frame.
12. Put boards under the gangs or shanks.
13. Start the tractor. Use the tractor hydraulics to retract the wing lift cylinders.
14. Stop the engine, apply the park brake, and take the ignition key with you.
15. Block up the machine to remove the weight from the tires.
16. Use the front hitch jack (1) to support the front hitch of the machine.
17. Disconnect the machine from the tractor. See the information for disconnecting the machine from the tractor.
18. Apply grease to the surfaces of the cylinder rods that are still showing.




Fig. 11




Fig. 12

4.3.2 Prevent corrosion of extended hydraulic cylinders

Store the machine with the cylinders in the retracted position. If the machine is stored with cylinders in the extended position, periodically cycle the cylinder. If a cylinder must be stored in the extended position without being cycled, the following corrosion prevention must be done.

Procedure

1. Use a dry cloth or cloth with solvent to clean any dirt from the cylinder shaft.
2. Prepare a mixture of 60 percent oil based rust inhibitor and 40 percent Kerosene.
3. Use a cloth to apply a thin layer of this mixture to the surface of the chrome plated shaft. Number one fuel oil can be replaced with Kerosene. A good grade purpose made product can be used for this procedure.
4. Follow manufacturer instructions for applying purpose made products.
5. Inspect and apply the mixture again at three to six month intervals.

4.3.3 Remove the machine from storage

Complete the following steps to remove the machine from storage.

Procedure

1. Connect the machine to the tractor.
2. Use the tractor hydraulics to extend the wing fold cylinders. Extend the wing fold cylinders until the holes in the end of the wing fold cylinders align with the holes in the mounts.
3. Stop the engine, apply the tractor park brake, and take the key with you.
4. Install the cylinder rod (1) of the wing fold cylinders to the mount on the wing frames. Use the existing hardware to fasten the wing fold cylinders.
5. Check the air pressure in all the tires.
6. Inspect all the hydraulic hoses and the connections for leaks and repair as necessary.
7. Make sure the safety signs are visible and not damaged.




Fig. 13

5 Troubleshooting

5.1 Troubleshooting	117
---------------------------	-----

5.1 Troubleshooting

Too much seed cracking.	
Cause(s)	Solution(s)
Air stream velocity is too great.	Decrease the blower speed.

The seed boots are plugging.	
Cause(s)	Solution(s)
Turning too sharply with boots in the ground.	Always lift ground opener before turning.
The ground openers have been left in the ground when the machine is backed up.	

There is oil on the seed lines.	
Cause(s)	Solution(s)
The shaft seal failed on the hydraulic motor.	Replace the seal. Do not disassemble hydraulic motor. The shaft seal is an external replacement.

The hydraulic motor is slow.	
Cause(s)	Solution(s)
The monitor set to the wrong blower speed setting.	See the information for the terminal.
The tractor is not putting out sufficient oil.	Have the tractor dealer inspect the tractor hydraulics.
The hydraulic couplers are bad.	Check the couplers on the tractor and the hoses. Try different couplers.

Seeding is uneven.	
Cause(s)	Solution(s)
The plenum is plugged.	Clean out the plenum.
The plenum is leaking	Adjust the plenum bulkheads and cylinder.
	Seal the plenum access covers.
The final run is plugged.	Clear the obstruction.

The final runs are plugged.	
Cause(s)	Solution(s)
The fan speeds are too low.	Increase the fan speed.
The venturi is blocked.	Clear the blockage.
The seed boot is blocked.	Clear the blockage.

The final runs are plugged.	
Cause(s)	Solution(s)
The seed rate is too high .	Slow down or decrease the seed rate.
The plenum is leaking.	Adjust the plenum bulkhead and cylinder.
The final run hoses are not routed properly.	Remove all the slack in the hoses with the toolbars fully extended with the machine up.

The product is not shutting off at hopper.	
Cause(s)	Solution(s)
The hopper gates are not closing.	Re-time the rack and pinion.
	Clear debris from the gates and sliders.

The meter does not turn.	
Cause(s)	Solution(s)
The meter is jammed.	Clear the jam (alarm will occur).
The key has fallen out.	Replace the key in the gearbox and shaft.
The gearbox and motor have become disconnected.	Remove the cover and reset the set screw in transition.
No power/communication (alarm will occur).	Check the fuses and the electrical connections.
No rate set in the terminal.	Set the rate in the terminal.
Section/product is not on.	Turn on the section/product.
The minimum speed is not met.	Exceed the minimum speed set point 1.6 km/h (1 mph).
The work switch is not enabled.	Enable the master apply switch.
	Be sure the implement work switch is down.

The meter turns but no product is delivered.	
Cause(s)	Solution(s)
The product may be bridged.	Clear the debris from above the meter.
The product gate is not open.	Open the product gate.

The ground speed is erratic.	
Cause(s)	Solution(s)
The sensor does not have a clear view to the sky.	Move into an open area.
	Clear the debris from the sensor.
The sensor is defective.	Replace the sensor on the wing tip.
The wiring is defective.	Check the connections.
	Check for broken or damaged wires.

The fan speed is erratic.	
Cause(s)	Solution(s)
The sensor is not adjusted correctly.	Adjust the sensor between 1 mm and 3 mm away from the target.
The sensor is damaged.	Replace the sensor.
The wiring is defective.	Check for broken or damaged wires.

The hopper full/empty sensor is not operating correctly (status light: green=empty, red=full).	
Cause(s)	Solution(s)
The sensitivity is set too strong.	Turn the screw out to relieve the sensitivity.
The sensing face is blocked.	Remove the blockage and clean the sensor face.
The wiring is defective.	Check for broken or damaged wires.
The sensor is defective.	Replace the sensor.

The machine does not apply seed.	
Cause(s)	Solution(s)
The minimum speed is not met.	Increase the speed.
The master apply switch is not enabled.	Press the master apply button.
The implement switch is not activated.	Lower the implement.
The fan is not active.	Turn on the fan and set the speed.
The down pressure is not active.	Turn on the down pressure.
No rate is set in the monitor.	Set the rate.
No calibration number is populated.	Calibrate meter and enter the value.

The downpressure is not controlling.	
Cause(s)	Solution(s)
The hydraulics are not on.	Turn the hydraulics on constant.
The oil flow from the tractor is not sufficient.	Increase the oil flow from the tractor.
	Check the hydraulic couplers and hoses.

The fan speed is not controlling.	
Cause(s)	Solution(s)
The hydraulics are not on.	Turn the hydraulics on.
The oil flow from the tractor is not sufficient.	Increase the oil flow from the tractor.
	Check the hydraulic couplers and hoses.
The case drain pressure is too high.	Check the case drain coupler and hoses.

The seeding rates are not accurate	
Cause(s)	Solution(s)
The calibration number is bad.	Calibrate again.
The ground speed is too slow.	Increase the ground speed.
	Change the meter roll and calibrate again.
The ground speed is too fast.	Decrease the ground speed.
	Change the meter roll and calibrate again.

There is no communication from the implement.	
Cause(s)	Solution(s)
The implement is not connected to the tractor.	Connect the ISOBus harness and power cable to the tractor.
There is no power from the tractor.	Fully power up the tractor with the VT.
	Check for power at the ISOBus plug on the tractor

The implement switch does not work correctly.	
Cause(s)	Solution(s)
The targets are missing.	Replace the targets.
The wiring is defective.	Check for broken or damaged wires.
The sensor is defective.	Replace the defective sensor.
The resistor is bad.	Replace the bad resistor.

No fan speed.	
Cause(s)	Solution(s)
The hydraulics are not connected to the tractor	Connect the hoses to the hydraulic ports
The hydraulics are connected to the incorrect couplers	
The fan control valve is not connected.	Check for broken or damaged wires.
	Check the control valve connections.
The fan speed sensor is faulty.	Replace the fan speed sensor.

The fan speed is low.	
Cause(s)	Solution(s)
The tractor hydraulic flow setting is too low.	Increase the hydraulic flow.
The fan speed sensor is faulty.	Replace the fan speed sensor. .

The fan speed is high.	
Cause(s)	Solution(s)
The fan control valve is not connected.	Check for broken or damaged wires.
	Check the control valve connections.
The fan speed sensor is faulty.	Replace the fan speed sensor.

Case drain pressure error.	
Cause(s)	Solution(s)
The case drain coupler is not connected.	Connect the case drain coupler to the port on the tractor.
The case drain line has a restriction.	Check the coupler.
	Check the hoses for a kink or pinch.
The case drain is connected to a pressure port.	Disconnect the pressure port and connect to the correct port on the tractor.

Planting too deep - double-disc opener.	
Cause(s)	Solution(s)
The press wheel is adjusted too high.	Lower the press wheel adjustment.
The down pressure is too excessive.	Decrease the down pressure.
The seed bed is too loose.	Use stroke control depth stops.
The drill is not level front to rear.	Level the drill.

Planting too shallow - double-disc opener.	
Cause(s)	Solution(s)
The press wheel is adjusted too low.	Adjust the press wheels.
The down pressure is insufficient.	Increase the down pressure.

Uneven seeding depth - double-disc opener.	
Cause(s)	Solution(s)
The press wheel depth is not properly adjusted.	Adjust the press wheels.
The seed depth is shallow behind tractor tires.	Increase the down pressure behind the tractor tires.

6 Specifications

6.1 Specifications	123
6.2 Transport dimensions	126
6.3 Minimum tow vehicle weight	127
6.4 Maximum transport speed	128
6.5 Lubrication specifications	129
6.6 Frame and rear hitch tire air pressure	130
6.7 SAE fastener torque specifications	131
6.8 Torque specifications for hydraulic tubes and fittings	132
6.9 Torque specifications for O-ring boss plugs, adjustable fitting lock nuts and JIC-37 Seats	133

6.1 Specifications

Size	Sections	Power requirements	Base weight
30 ft. (9.14 m)	3	225 hp to 325 hp (168 kW to 242 kW)	24400 lb (11091 kg)

Size	Seed openers	Fertilizer openers	Weight with fertilizer banders	Ballast kit weight
30 ft. (9.14 m)	48	24	29000 lb (13154 kg)	1280lbs (581 kg)

Tire sizes	
Main frame support tires	440/55R18 159A8/B TL (GY)
Wing frame support tires	440/55R18 137A8/B TL
Floating rear hitch tire	12.5L-15 8 ply

Toolbar specifications	
Disc size	18 in (45.7 cm)
Seed depth	0 to 3 inch (0 cm to 7.6 cm)
Row spacing	6 to 9 inch (15 cm to 23 cm) pair row

Hopper capacity (60/40 split)	
Front hopper	105 bu (3700 L)
Rear hopper	70 bu (2500 L)

Hydraulic requirements		
35 gal/min (132.5 L/min) flow rate	4 hydraulic remotes	1 case drain

Electrical requirements	
12 volts	45 amps peak

6.2 Transport dimensions




Fig. 1

Model	(A) Transport height	(B) Transport width	(C) Transport Length
NT-30	13 ft 1 1/2 in(4.0 m)	11 ft 6 in (3.5 m)	27 ft 9 in (8.46 m)

6.3 Minimum tow vehicle weight

NOTE: Minimum tow vehicle weight calculated for a machine with single disc openers, mid-row banders and full hoppers towing a 11.8 cu m (335 bushel) cart full of product.

Model	Minimum tow vehicle weight
NT-30	48500 lbs (22000 kg)

6.4 Maximum transport speed

Maximum speed:

20 mph (30 km/h)

6.5 Lubrication specifications


Model	Lubrication fitting
All	No. 2 multi-purpose lithium grease

6.6 Frame and rear hitch tire air pressure

Tire	Three-section Frame
Main Frame Support Tires	73 psi (503 kPa)
Wing Frame Support Tires	40 psi (276 kPa)
Floating Hitch Tires	36 psi (248 kPa)

6.7 SAE fastener torque specifications

The torque specifications below are for UNC and UNF thread fasteners, plated or unplated, as received from the supplier. Fasteners can be dry or lubricated with normal engine oil. Specifications do not apply if graphite, moly-disulfide, or other extreme pressure lubricant is used.

SAE Grade Number	2				5				8*			
Bolt head identification												
Bolt size maximum	Foot pounds		Newton meters		Foot pounds		Newton meters		Foot pounds		Newton meters	
1/4 in	5	6	7	8	9	11	12	15	12	15	16	20
5/16 in	10	12	14	16	17	20.5	23	28	24	29	33	39
3/8 in	20	23	27	31	35	42	48	57	45	54	61	73
7/16 in	30	35	41	47	54	64	73	87	70	84	95	114
1/2 in	45	52	61	70	80	96	109	130	110	132	149	179
9/16 in	65	75	88	102	110	132	149	179	160	192	217	260
5/8 in	95	105	129	142	150	180	203	244	220	264	298	358
3/4 in	150	185	203	251	270	324	366	439	380	456	515	618
7/8 in	160	200	217	271	400	480	542	651	600	720	814	976
1 in	250	300	339	406	580	696	787	944	900	1080	1220	1464
1 1/8 in					800	880	1085	1193	1280	1440	1736	1953
1 1/4 in					1120	1240	1519	1681	1820	2000	2468	2712
1 3/8 in					1460	1680	1980	2278	2380	2720	3227	3688
1 1/2 in					1940	2200	2631	2983	3160	3560	4285	4827
Bolt head identification marks as per grade. Manufacturing marks may vary.									*Thick nuts must be used with grade-8 bolts.			

6.8 Torque specifications for hydraulic tubes and fittings

Standard torque specifications for hydraulic tubes and fittings							
O-Ring face seal fittings (face seal end)							
Size	Tubing O.D.		Thread size	Foot pounds		Newton meters	
	Inches	Millimeters		Minimum	Maximum	Minimum	Maximum
4	1/4 in	6.4	9/16 in - 20	10	12	14	16
6	3/8 in	9.5	11/16 in - 16	18	20	24	27
8	1/2 in	12.7	13/16 in - 16	32	35	43	47
10	5/8 in	15.9	1 in - 14	46	50	60	68
12	3/4 in	19.1	1 3/16 in - 12	65	70	90	95
14	7/8 in	22.2	1 3/16 in - 12	65	70	90	95
16	1 in	25.4	1 7/16 in - 12	92	100	125	135
20	1 1/4 in	31.8	1 11/16 in	125	140	170	190
24	1 1/2 in	38.1	2 in - 12	150	165	200	225

6.9 Torque specifications for O-ring boss plugs, adjustable fitting lock nuts and JIC-37 seats

Torque specifications for O-ring boss plugs, adjustable fitting lock nuts and JIC-37 seats				
Size	Foot pounds		Newton meters	
	Minimum	Maximum	Minimum	Maximum
4	6	10	8	14
5	10	15	14	20
6	15	20	20	27
8	25	30	34	41
10	35	40	47	54
12	60	70	81	95
14	70	80	95	109
16	80	90	108	122
20	95	115	129	156
24	125	140	163	190

7 Accessories

7.1 Fertilizer bander attachment	137
7.1.1 Adjusting fertilizer bander depth	137

7.1 Fertilizer bander attachment

The optional fertilizer bander attachment (1) applies anhydrous ammonia or fertilizer between the two furrows that are made by the opening disc assemblies. The fertilizer bander attachment is installed forward of the opening disc assemblies.




Fig. 1

The depth at which the fertilizer bander applies the fertilizer is set using a cam block (1). The slots (2) in the cam block determine the depth of the fertilizer. The deeper the slot in the cam block; the deeper the fertilizer is applied.

IMPORTANT: *When operating in rocky soil conditions, do not operate at a high rate of speed. High speeds in rocky conditions will damage the fertilizer bander attachment.*




Fig. 2

7.1.1 Adjusting fertilizer bander depth

Before starting the procedure

To adjust the fertilizer bander depth the machine must be connected to the correct size of tractor to operate the machine.

Procedure

1. Raise the frame of the machine until the bander discs are off of the ground.
2. Stop the tractor. Stop the engine, apply the tractor park brake, and take the ignition key with you.

7. Accessories

3. Place a wooden block below one of the discs (1) on the fertilizer bander attachment that is to be adjusted.
4. Start the tractor and lower the machine to the ground.
5. Stop the tractor. Stop the engine, apply the tractor park brake, and take the ignition key with you.




Fig. 3

6.  **CAUTION:** Make sure the fertilizer bander disc is firmly supported by the wooden block. If the fertilizer bander disc is not firmly supported then start the tractor, raise the machine, and reposition the wooden block.

Remove the bolt (1) and washer (2) securing one end of the cam block (3) for the bander disc (4) being supported by the wooden block.




Fig. 4

7. Slide the cam block out of the bander frame.
8. Install the cam block in the bander frame so the desired depth groove in the cam block will contact the bander disc strut.
9. Secure the cam block in the bander frame using the existing bolt and washer.
10. Start the tractor and raise the machine until the bander disc is off of the wooden block.
11. Stop the tractor. Stop the engine, apply the tractor park brake, and take the ignition key with you.
12. Remove the wooden block from below the bander discs.

After finishing the procedure

Use the same procedure to adjust the remaining bander disc on the fertilizer bander attachment and the other bander attachments.

8 Assembly

8 Assembly	139
8.1 Prepare for assembly	141
8.1.1 Service parts	141
8.2 Assemble the cast boot	142
8.3 Checklists	143
8.3.1 Pre-delivery checklist	143
8.3.2 Delivery checklist	143

8.1 Prepare for assembly



WARNING: Components can be heavy.

Severe injury can result from improper lifting technique.

Use appropriate lifting equipment for heavy components.

Read this section carefully before assembly. Refer to the Parts Catalog for additional component illustrations while assembling the machine.

Part numbers are shown on labels on the parts.

Hardware numbers are shown on labels on the hardware or on the container the hardware is in.

Carefully remove all the parts and hardware included. Make sure nothing was damaged or missing.

Tighten all hardware according to standard torque values unless specified in these instructions. See the torque charts in this publication for more information.

Always replace hardware with the same grade or class.

Use all the nuts and bolts in the correct locations. This will prevent damage to the machine.

IMPORTANT: *When two or more bolts are being used on a part, always insert the bolts and loosely tighten the nuts. Once the correct location has been reached, tighten the nuts evenly to prevent misalignment or distortion of the parts. Tighten all U-bolt nuts evenly and to the same torque to prevent misalignment or distortion.*

Select a large, flat, and hard surface for assembly of machine.

IMPORTANT: *Keep all parts in the assigned containers until the parts are to be used.*

NOTE: *Some items will be assembled at the factory.*

Right-hand and left-hand, as used in this manual, are determined by facing the direction the machine will travel when in use.

8.1.1 Service parts

The illustrations and part numbers in this publication are supplied for component identification only when assembling the machine. When ordering replacement parts, always use the part numbers from the parts catalog.

For a complete list of available service parts, contact your dealer.

8.2 Assemble the cast boot

Procedure

1. Assemble the boot (1), hinge pin and torsion spring as shown.
2. Put the assembly tool (2) on the exposed pin.
3. Use a wrench to turn the tool until it touches the spring.
4. Turn the spring until it goes past the retainer slot.
5. Put the spring retainer pin (3) into the retainer slot.

Result

Make sure the pin is flush with the face of the strut or it could fall out during operation.




Fig. 1

6. Remove the assembly tool and install the retainer plates (4).
7. Install the two flat washers (5), lock washers (6) and 1/2 inch hex bolts (7).
8. Push on the top of the boot until the front edge of the boot evenly rides on the disc.
9. Tighten the two 1/2 inch hex bolts (7).

8.3 Checklists

8.3.1 Pre-delivery checklist

8.3.2 Delivery checklist

- Make sure dealer personnel are on location when starting the machine in the field. Make sure all systems work correctly. Look at the Operator's Manual to make sure the machine is set up correctly.
- Make sure the owner understands the Warranty of the machine. Complete the Warranty Registration form and list the serial number of the machine. The dealer and the owner must each sign the form.
- Make sure the machine operator understands the Safety Section. Tell about the different warning decals for dangerous operating procedures or conditions. Tell the owner of the machine to study the Operator's Manual with each operator of the machine.
- If necessary, make sure the operator knows how to adjust, connect, or disconnect other attachments to the machine.
- Make sure the operator knows the locations and functions of the controls.
- Tell the operator about the adjustments for different field conditions.
- Tell the operator about how important correct lubrication and servicing is.
- Make sure the operator understands the light system when operating a machine on the road at night and during the day. The tail lamps, warning lamps, and SMV (Slow Moving Vehicle) emblem must be used for warning operators of other vehicles. Tell the customer to know local government regulations that deal with movement of slow and over width vehicles.
- Give the Operator's Manual to the owner. Make sure the owner will study all sections of the manual.

Index

A

adjust the cast boot	77
agricultural chemicals	17
assembly	
prepare	141

B

bins	
load	100
blower	66
blower speed	66

C

Cam block	78, 137
cast boot	
assemble	142
chemical ingestion hazard	
safety sign	34
cleanout tray latch	68
crushing hazard	
safety sign	35, 37

D

delivery checklist	143
disconnect	59
disposal of waste	43, 45
do not step	
safety sign	37
down pressure	
set	98
drill section	
calibrate	97
drill to tractor hydraulic couplers	62

E

electrical shock hazard	
safety sign	35
exhaust warning	16
explosion hazard	
safety sign	37
external master switch	95

F

fall off hazard	
safety sign	36
Fertilizer bander attachment	
Adjusting depth	78, 137
fire prevention and first aid	21
flying debris	17
flying objects hazard	
safety sign	36
frame height cylinders	

put in phase	65
Frame height cylinders	
Phasing	65

G

general maintenance information	20
general safety alert hazard	
safety sign	33, 34

H

high pressure leaks	22
hopper capacity	
safety sign	38
hydraulic fluid injection hazard	
safety sign	34
hydraulic fold system	
bleed air	63
hydraulic jack	55
Hydraulic lift assist	88
hydraulic lift system	
bleed air	62
hydraulic lock-out valve	
safety sign	38
hydraulic systems	62
hydraulic tubes and fittings	
torque specifications	132, 133

I

implement settings	
change	97
implement software identification	94
information messages	11
intended use	43
introduction	43
ISOBUS connector	56

L

ladder and platform	53
loose pinch point	86
loss of machine control hazard	
safety sign	34
lubrication	
lubrication points	107
lubrication and maintenance chart	107
lubrication fitting locations	108
lubrication points	
lubrication	107
lubrication specifications	129

M

machine for transport	
prepare	71
machine from the tractor	59

Index

machine identification	45	replacement parts	23, 43
main work screen	91	restrictor fitting	
maintenance	103	safety sign	36
major components	48	rigid scraper	86
marker lamps	31		
master switch	94	S	
maximum speed	128	SAE fastener	
maximum speed sign		torque specifications	131
safety sign	33	safety general information	14
meter latches	67	safety messages	11
meter shaft adjustment	68	safety sign overview	32
metering wheels		safety signs	11
change	67	safety symbol	11
minimum tow vehicle weight	127	seat instructions	15
		seed depth	
N		adjust	84
narrow-transport single disc drill	47	check	82
negative tongue weight hazard		Seed depth	
safety sign	33	Collar sequences	83
		Initial collar sequences	84
O		seed depth adjustment	85
opener shims	87	seed depth collar chart	
Opening disc scraper		safety sign	37
Adjusting	77	serial number description	45
operator manual storage	50	serial number plate	45
		service	
P		wheel bearings	112
Packing tire	81	service parts	141
patent pending		shield and guards	16
safety sign	40	smv emblem	
personal protective equipment	15	safety sign	39
pinch hazard		software icon descriptions	90
safety sign	36	specifications	125
pinch point	36		
plenum		T	
cleaning	69	terminal information	94
lower	69	terminal master switch	95
plenum operation	69	the machine for seeding	
plenum valve		prepare	73
safety sign	38	tight pinch point	87
pre-delivery checklist	143	tire air pressure	130
prepare for		tire safety	22
storage	113	Toolbar	88
prepare for operation	14	Toolbar down pressure	88
prevent		Toolbar lock-out valve	30
corrosion of extended hydraulic cylinders	114	toolbar locks	
product hopper lids	54	lock	27
product rate		unlocking	28
set	99	totals	102
proper disposal of waste	43, 44	transport	
		maximum speed	128
R		transport dimensions	126
reflector, orange		transporting hazard	
safety sign	39	safety sign	35
reflector, red		travel on public roads	18
safety sign	39	troubleshooting	117
reflector, yellow		turn	89
safety sign	39		
remove from		U	
storage	114	U.S. patents	
		safety sign	40

units of measurement 43

V

virtual switch box 95

W

wing lock pins
 install 24
 remove 25
wings to the center frame
 level 75
wireless blockage monitor 70
word to the operator 12

